

BK-9

BACKING KEYBOARD

Roland

Rhythm List

Contents

Rhythm List	2
8 BEAT /16 BEAT.....	2
LIVE BAND.....	2
ROCK.....	2
DISCO /DANCE.....	2
BALL ROOM.....	3
50's & 60's.....	3
JAZZ / BLUES.....	4
LATIN.....	4
BOSSA / SAMBA.....	4
TRADIT / WORLD.....	4

Recalling a Rhythm and a division via MIDI	6
E-Series compatibility.....	6

Rhythm List

No.	Name	CC00	CC32	BPM	TS
8 BEAT /16 BEAT					
0001	Space Beat	75	2	80	4/4
0002	Boygrouop	75	3	90	4/4
0003	Sparks Pop	75	4	120	4/4
0004	Fame Beat	75	5	85	4/4
0005	David Pop	75	6	80	4/4
0006	Fun Pop	75	7	161	4/4
0007	Diamond Pop	75	8	92	4/4
0008	Flood Pop	6	1	98	4/4
0009	Fate Beat	6	80	78	4/4
0010	Jessie Beat	6	4	88	4/4
0011	Killing Beat	6	3	128	4/4
0012	Pink Beat	6	5	92	4/4
0013	Romantic Beat	6	81	85	4/4
0014	Time Pop	71	2	128	4/4
0015	Frank's Way	6	117	76	4/4
0016	Easy Ballad	6	118	105	4/4
0017	Lying Beat	6	119	130	4/4
0018	Sky Beat	6	120	104	4/4
0019	Home Beat	6	121	64	4/4
0020	Slow Beat	6	122	60	4/4
0021	Thick Beat	6	123	78	4/4
0022	Due Beat	6	124	99	4/4
0023	Acoustic Ballad	6	125	78	4/4
0024	Adult Contemp	6	126	76	4/4
0025	Contemp Country	6	127	68	4/4
0026	Gold Slow Beat	71	0	80	4/4
0027	Gold Medium Beat	71	1	118	4/4
0028	Romantic Ballad	6	115	70	4/4
0029	Angel Ballad	6	109	75	4/4
0030	Sunshine Pop	6	114	130	4/4
0031	Blue Pop	6	110	110	4/4
0032	British Pop	6	111	125	4/4
0033	Sister Pop	6	113	184	4/4
0034	Love Beat	6	90	66	4/4
0035	70's Pop	6	106	112	4/4
0036	Night Pop	6	94	58	4/4
0037	Happy Pop	16	21	103	4/4
0038	Easy Groove	6	85	68	4/4
0039	Groovy Pop	6	101	84	4/4
0040	Warm Pop	6	105	92	4/4
0041	Fast Pop	6	97	145	4/4
0042	80's Pop	6	86	178	4/4
0043	Sunny Pop	6	102	104	4/4
0044	Color Beat	6	104	118	4/4
0045	Guitar Pop	6	48	72	4/4
0046	Trendy Beat	6	50	85	4/4
0047	Full Pop	6	51	88	4/4
0048	Morn Pop	6	52	80	4/4
0049	Billy Beat	7	114	68	4/4
0050	Breakin' Beat	7	115	72	4/4

No.	Name	CC00	CC32	BPM	TS
0051	Fancy Beat	7	116	62	4/4
0052	US Country Pop	7	117	83	4/4
0053	Gold Beat	7	118	66	4/4
0054	Friendly Beat	7	102	59	4/4
0055	Radio Pop	7	101	120	4/4
0056	Midnight Ballad	4	35	70	4/4
0057	Pop Ballad	4	34	68	4/4
0058	Light Soul	7	87	74	4/4
0059	Schlager Beat	5	41	103	4/4
0060	Nice Groove	7	92	100	4/4
0061	Cute Pop	7	95	94	4/4
0062	Smile Pop	7	93	100	4/4
0063	Analog Beat	7	96	85	4/4
0064	Moonlight Pop	7	94	98	4/4
0065	Ballad Slow Rock	7	103	90	6/8
0066	Lovely Ballad	4	36	120	4/4
0067	Latin Beat	7	90	94	4/4
0068	70's Groove	7	83	120	4/4
0069	UK Pop	7	82	124	4/4
0070	Contemp Beat	7	53	70	4/4
0071	Simply Pop	7	54	75	4/4
0072	Home Pop	7	55	80	4/4
0073	Power Pop	7	56	80	4/4
0074	Groovin'	7	58	93	4/4
0075	Light Beat	7	60	98	4/4
0076	US Shuffle	4	22	88	4/4
0077	UK Shuffle	4	23	107	4/4
0078	Shuffle Fusion	4	24	120	4/4
LIVE BAND					
0079	Heaven Pop	75	24	94	4/4
0080	Blake Band	75	16	77	4/4
0081	Honey Pop	75	17	103	4/4
0082	Eric Beat	68	14	98	4/4
0083	Strummin' Pop	68	11	93	4/4
0084	The Unplugged	68	13	108	4/4
0085	Amazing Gospel	68	12	61	6/8
0086	Night Ballad	68	5	50	4/4
0087	6_8 Ballad	68	7	59	6/8
0088	6_8 Pop	68	9	66	6/8
0089	Unplugged Pop	68	2	80	4/4
0090	Unplugged Ballad	68	1	88	4/4
0091	Cool Live Band	68	8	92	4/4
0092	Acoustic Pop	68	6	96	4/4
0093	Live Pop	68	3	108	4/4
0094	Guitar Shuffle	68	10	120	4/4
0095	Real Band	68	4	128	4/4
0096	Cool Pop	68	16	108	4/4
0097	Light Pop	68	15	120	4/4
0098	Soul Pop	68	17	78	4/4
0099	Bright Pop	68	18	93	4/4
ROCK					

No.	Name	CC00	CC32	BPM	TS
0100	Burnin' Rock	75	18	110	4/4
0101	Pink Rock	75	19	104	4/4
0102	Hard Electro	75	20	120	4/4
0103	Teutonia	75	21	123	4/4
0104	Rolling Rock	1	1	108	4/4
0105	Green Rock	1	83	84	4/4
0106	Spring Rock	1	80	114	4/4
0107	Broken Beat	1	81	72	4/4
0108	Straight Rock	1	82	130	4/4
0109	Joe's Rock	1	72	88	4/4
0110	Countdown Rock	1	69	118	4/4
0111	Cool Shuffle	1	76	126	4/4
0112	Breaky Rock	1	68	120	4/4
0113	Dark Rock	1	70	126	4/4
0114	JuliRock	1	73	112	4/4
0115	LoveRock	1	77	85	4/4
0116	Happy Beat	1	64	104	4/4
0117	Bright Rock	1	59	107	4/4
0118	Easy Rock	1	61	131	4/4
0119	Electro Rock	1	62	126	4/4
0120	New Metal	1	63	83	4/4
0121	MunichRock	1	74	88	4/4
0122	Schlager Rock	1	75	126	4/4
0123	German90Pop	1	71	98	4/4
0124	Simple Rock	1	65	90	4/4
0125	Rock Beat	1	66	80	4/4
0126	Soft Rock	1	60	91	4/4
0127	Light Rock	1	35	86	4/4
0128	Groovy Rock	1	36	101	4/4
0129	Smooth Rock	1	37	106	4/4
0130	Big Rock	1	38	120	4/4
0131	Power Rock	1	39	130	4/4
0132	Fire Rock	1	40	136	4/4
0133	Fast Rock	1	41	172	4/4
0134	Rock Shuffle	1	42	135	4/4
DISCO /DANCE					
0135	Child's House	75	10	129	4/4
0136	Horses' Dance	75	11	126	4/4
0137	Club Traxx	75	12	128	4/4
0138	Good Rap	75	13	86	4/4
0139	Young Disco	75	14	128	4/4
0140	Party Mix	75	15	126	4/4
0141	Peas Disco	66	1	128	4/4
0142	California Disco	66	2	122	4/4
0143	Edge Disco	66	3	128	4/4
0144	Saxo Disco	66	4	127	4/4
0145	Broken Dance	66	5	130	4/4
0146	Fire Beat	66	11	126	4/4
0147	Hitmix	66	6	132	4/4
0148	Beat Generation	66	60	128	4/4
0149	Seventies	66	61	131	4/4

Rhythm List

No.	Name	CC00	CC32	BPM	TS
0150	Volare Gipsy	66	62	116	4/4
0151	Night's Dance	66	63	109	4/4
0152	Hung Disco	66	64	125	4/4
0153	Jamiro Dance	66	57	108	4/4
0154	Just Disco	66	58	103	4/4
0155	2000's Disco	66	59	122	4/4
0156	Slow Disco	66	56	101	4/4
0157	Gold Disco	66	65	124	4/4
0158	Ladies Dance	66	28	126	4/4
0159	UK Dance	66	32	117	4/4
0160	Housing	66	27	120	4/4
0161	Survive Disco	66	21	117	4/4
0162	Dancin'	66	26	118	4/4
0163	Earth Boogie	66	34	130	4/4
0164	DJ Groove	66	33	103	4/4
0165	Euro Dance	66	5	140	4/4
0166	Dream Dance	66	3	130	4/4
0167	Ibiza Dance	66	6	132	4/4
0168	Ibiza Night	66	12	140	4/4
0169	House Mallorca	66	10	130	4/4
0170	Club House	66	9	134	4/4
0171	DJ Techno	66	7	140	4/4
0172	Hard Techno	66	8	146	4/4
0173	80's Techno	66	2	130	4/4
0174	Ballerman	5	48	134	4/4
0175	Latin Dance	22	39	106	4/4
0176	Gipsy Dance	61	7	122	4/4
0177	Barry Dance	66	13	132	4/4
0178	70's Disco	66	4	124	4/4
0179	Poppin' Schlager	5	1	120	4/4
0180	Folk Schlager	5	2	120	4/4
0181	Schlager Shuffle	66	30	112	4/4
0182	Schlagermichl	66	29	130	4/4
0183	Stadlschlager	66	31	90	4/4
0184	70's Schlager	66	22	136	4/4
0185	Alpenschlager	66	25	123	4/4
0186	Schlag Disco Fox	66	35	125	4/4
0187	AlpenParty	66	24	123	4/4
0188	AlpenBallade	66	23	89	6/8
0189	Disco Schlager	5	46	130	4/4
0190	Latin Schlager	5	47	122	4/4
0191	Dance Schlager	5	45	136	4/4
0192	Happy Schlager	5	44	129	4/4
0193	Party Schlager	5	43	124	4/4
0194	Schlager Pop	5	42	122	4/4
0195	Latin Disco	2	92	130	4/4
0196	Reggaetone	8	12	96	4/4
0197	Phunk Beat	28	21	131	4/4
0198	Spear Beat	28	22	120	4/4
0199	Baby Beat	28	19	93	4/4
0200	Funky Groove	28	20	109	4/4

No.	Name	CC00	CC32	BPM	TS
0201	Downtown Funk	28	17	120	4/4
0202	Wahoo Groove	28	18	117	4/4
0203	Rap Anthem	33	13	93	4/4
0204	Breath Rap	33	14	96	4/4
0205	Cool Rap	33	13	95	4/4
0206	Now Hip Hop	66	16	96	4/4
0207	HipHop Beat	66	14	86	4/4
0208	Hip'n Hop	66	15	102	4/4
0209	Twostep	4	33	130	4/4
0210	Contemporary Pop	28	16	92	4/4
0211	Funky	3	27	103	4/4
0212	Funky Pop	3	26	108	4/4
0213	80's Groove	2	89	114	4/4
0214	70's Beat	2	90	122	4/4
0215	Smooth Contemp	28	12	93	4/4
0216	Light Contemp	2	91	94	4/4
0217	Acid Pop	28	13	123	4/4
0218	Wave Jazz	28	11	95	4/4
BALL ROOM					
0219	Gold Wien Waltz	17	55	174	3/4
0220	Wien Waltz	17	38	180	3/4
0221	Vienne	17	46	153	3/4
0222	Gold Slow Waltz	17	56	90	3/4
0223	Slow Waltz	17	39	90	3/4
0224	3_4 Boston	17	44	119	3/4
0225	French Valse	17	45	196	3/4
0226	It Valzer	17	57	178	3/4
0227	Moon Waltz	17	58	93	3/4
0228	Folk Valzer 1	17	42	176	3/4
0229	Folk Valzer 2	17	43	178	3/4
0230	Alpenwalzer	17	49	98	6/8
0231	Polca Disco	19	33	122	2/4
0232	It Polca	19	34	124	2/4
0233	Polca 1	19	25	116	2/4
0234	Polca 2	19	26	124	2/4
0235	Manouche	69	4	135	4/4
0236	Paso Doble	40	4	123	4/4
0237	Paso Doble 2	40	5	124	4/4
0238	Paso Doble 3	40	6	122	4/4
0239	Gold Tango	26	17	128	4/4
0240	Cool Tango	26	15	120	4/4
0241	It Tango	26	18	116	4/4
0242	Folk Tango 1	26	13	118	4/4
0243	Folk Tango 2	26	14	125	4/4
0244	Tango	26	12	118	4/4
0245	Mazurca 1	17	40	138	3/4
0246	Mazurca 2	17	41	145	3/4
0247	Tarantella Disco	53	7	130	2/4
0248	Tarantella	53	6	130	2/4
0249	Gold Foxtrot	34	14	120	4/4
0250	Gold Jive	7	119	174	4/4

No.	Name	CC00	CC32	BPM	TS
0251	Jive	69	1	174	4/4
0252	Quick Step	69	2	210	4/4
0253	Madison	69	3	128	4/4
0254	It Fox	50	88	96	4/4
0255	It Swing Fox	50	89	175	4/4
0256	Fox Latino	50	90	94	4/4
0257	Slow Fox	50	81	120	4/4
0258	Gold Rhumba	23	13	100	4/4
0259	Rhumba	23	11	110	4/4
0260	Bolero	55	2	109	4/4
0261	It Beguine	39	27	118	4/4
0262	Romantic Beguine	39	26	107	4/4
0263	Beguine	39	16	105	4/4
0264	Gold Cha Cha	24	17	128	4/4
0265	Cha Cha	24	14	130	4/4
0266	Simply Cha Cha	24	13	120	4/4
0267	Cool Cha Cha	24	15	129	4/4
0268	It Mambo	38	14	176	4/4
0269	It Fast Mambo	38	15	188	4/4
0270	It Cumbia	46	5	85	4/4
0271	Simple Cumbia	46	4	95	2/4
0272	It Hully Gully	22	50	130	4/4
0273	Disco Gully	66	11	142	4/4
0274	It Meneito	22	48	94	4/4
0275	Meneaito	22	38	104	2/4
0276	Biguine	39	20	121	4/4
0277	It Bachata	22	49	132	4/4
0278	Gold Samba	27	26	100	4/4
0279	Ball Room Samba	27	21	113	4/4
0280	Big Samba	27	22	124	4/4
0281	Gold Bossa	22	47	124	4/4
0282	Cool March	20	23	128	4/4
0283	Gold Euro March	20	24	120	4/4
50's & 60's					
0284	50's Pop	75	0	138	4/4
0285	Fast Surf	75	1	162	4/4
0286	Over Rockin'	5	56	130	4/4
0287	Love Sl Rock	5	57	83	6/8
0288	UK Rock'N	5	51	176	4/4
0289	Baby Rock'N	10	39	118	4/4
0290	Go! Rock'N	5	36	160	4/4
0291	60's Rock'N	5	37	180	4/4
0292	Good Rock'N	10	24	168	4/4
0293	Blue Boogie	5	38	155	4/4
0294	Smooth Rock'N	10	22	122	4/4
0295	Clock Rock'N	10	23	176	4/4
0296	Brass Rock'N	10	25	181	4/4
0297	Easy Slow Rock	5	39	83	6/8
0298	50's Slow Rock	5	16	80	4/4
0299	Oldies	5	33	130	4/4
0300	Dream Slow Rock	5	32	71	4/4

Rhythm List

No.	Name	CC00	CC32	BPM	TS
0301	Rock'N Slow	5	35	125	4/4
0302	Go! Twist	10	30	160	4/4
0303	Twist	10	20	158	4/4
0304	Beach Surf	10	21	154	4/4
0305	Romantic 6_8	5	52	100	6/8
0306	Schlager 6_8	5	53	104	6/8
0307	GermanOldie	5	49	115	4/4
0308	Cool Slow Rock	5	22	96	6/8
0309	Dixie	11	7	140	4/4
0310	Combo Boogie	9	7	150	4/4
0311	Big Band Boogie	9	9	186	4/4
0312	Charleston	11	6	193	4/4
0313	Piano Rock'N	10	31	150	4/4
0314	Piano Shuffle	15	9	150	4/4
0315	Piano Ragtime	43	2	170	4/4
JAZZ / BLUES					
0316	BlueEyesBand	12	41	130	4/4
0317	OrganSwingMe- dium	12	42	145	4/4
0318	Organ Jazz Fast	12	43	200	4/4
0319	Gold Swing	12	44	133	4/4
0320	Swingin'	12	45	144	4/4
0321	Cool Big Band	12	46	206	4/4
0322	Breezy Swing	14	25	120	4/4
0323	Big Apple Band	14	26	110	4/4
0324	Biggest Band	14	24	130	4/4
0325	Bennys Big Band	14	23	198	4/4
0326	Midnight SWSwing	12	35	56	4/4
0327	Big Band Slow	14	18	61	4/4
0328	Big Band Medium	14	19	125	4/4
0329	Big Band Fast	14	20	170	4/4
0330	Swing Medium	12	31	130	4/4
0331	Modern Med Swing	12	33	113	4/4
0332	Orchestra Swing	12	36	124	4/4
0333	Jazz Big Band	14	22	164	4/4
0334	Swing Fast	12	32	243	4/4
0335	Jz Guitar Swing	12	37	232	4/4
0336	Pop Swing	12	38	135	4/4
0337	Gipsy Swing	12	38	208	4/4
0338	Soft Ballad	13	14	55	4/4
0339	Jazz Club	13	15	86	4/4
0340	Medium Jazz	13	16	100	4/4
0341	Smooth Med Swing	13	17	110	4/4
0342	Scat Swing	12	23	125	4/4
0343	Cool Swing	12	24	135	4/4
0344	Ensemble Swing	12	25	180	4/4
0345	Combo Fast Swing	12	26	220	4/4
0346	Slow Jz Waltz	17	28	106	3/4
0347	Medium Jz Waltz	17	23	120	3/4
0348	Piano Night	13	18	60	4/4
0349	Piano Jazz	12	27	150	4/4

No.	Name	CC00	CC32	BPM	TS
0350	Jimmys Groove	44	31	177	4/4
0351	Mustang Blues	44	32	116	4/4
0352	Cool Soul	44	30	115	4/4
0353	Soul	44	26	127	4/4
0354	R&B	44	18	106	4/4
0355	Sweet Blues	44	1	117	4/4
0356	Cool Blues	44	2	54	4/4
0357	Unplug Shuffle	15	11	124	4/4
0358	Midnight Blues	44	25	62	4/4
LATIN					
0359	Carlos Beat	22	45	116	4/4
0360	Oye Son	45	1	126	4/4
0361	Orchestr Cha Cha	24	16	122	4/4
0362	That's Mambo	38	13	92	4/4
0363	Bachata	22	40	126	4/4
0364	Go!Salsa	22	43	94	4/4
0365	Cuba Salsa	22	42	107	4/4
0366	Cool Merengue	22	41	126	4/4
0367	Fast Merengue	59	4	155	4/4
0368	Medium Gipsy	61	0	93	2/4
0369	Fast Gipsy	61	1	120	2/4
0370	Big Mambo	38	6	89	4/4
0371	Tradit Rhumba	23	6	98	4/4
0372	Acoustic Rhumba	23	12	130	4/4
0373	Arg Tango	26	6	120	4/4
0374	Mariachi	17	27	112	3/4
0375	Tradit Cumbia	46	2	98	4/4
0376	Calypso	35	4	165	4/4
0377	Limborock	35	3	86	4/4
0378	AfroPeruana	27	47	135	4/4
0379	Andina	27	48	95	4/4
0380	ChaChaCha	27	49	125	4/4
0381	Chundo	27	50	112	4/4
0382	Cumbia Neo	27	51	103	4/4
0383	Cumbia Nortena	27	52	140	4/4
0384	Cumbia Radio	27	53	104	4/4
0385	Cumbia Sonidera	27	54	85	4/4
0386	Cumbia Trad	27	55	102	4/4
0387	Duranguense	27	56	158	4/4
0388	Huaracha	27	57	93	4/4
0389	Latin Capital	27	58	175	4/4
0390	Latin Club	27	59	96	4/4
0391	Latin Pop	27	60	75	4/4
0392	Mariachi Fies	27	61	105	4/4
0393	MariachiTrad	27	62	103	4/4
0394	Merengue	27	63	160	4/4
0395	Latin Ska	27	64	188	4/4
0396	Son Cubano	27	65	94	4/4
0397	Son Jarocho	27	66	115	4/4
BOSSA / SAMBA					
0398	Agua Bossa	75	9	74	4/4

No.	Name	CC00	CC32	BPM	TS
0399	Organ Bossa	22	46	130	4/4
0400	Orchestral Bossa	70	2	98	4/4
0401	Jazz Bossa	22	44	120	4/4
0402	Sunshine Bossa	70	1	136	4/4
0403	Sweet Bossa	22	15	106	4/4
0404	Club Bossa	22	16	125	4/4
0405	Fast Bossa	22	18	173	4/4
0406	Guitar Bossa	22	28	100	4/4
0407	Night Bossa	22	17	150	4/4
0408	Organ Samba	27	25	100	4/4
0409	Orchestral Samba	27	24	116	4/4
0410	Acoustic Samba	27	23	108	4/4
0411	Brazilian Samba	27	9	102	4/4
0412	Sambalegre	27	10	130	4/4
0413	Guitar Samba	27	12	100	4/4
0414	Latin Fusion	22	26	140	4/4
0415	Jazz Latin	22	19	102	4/4
0416	Pop Reggae Br	27	40	93	4/4
0417	Funk Carioca	27	36	129	4/4
0418	MPB Funk	27	38	97	4/4
0419	Sertanejo	27	44	78	4/4
0420	Arrastape	27	27	134	4/4
0421	Guarana	27	37	96	3/4
0422	Pagode	27	39	96	4/4
0423	Samba-Enredo	27	43	130	4/4
0424	Samba	27	41	94	4/4
0425	Chorinho	27	32	100	4/4
0426	Samba-Duro	27	42	88	4/4
0427	Brega	27	30	103	4/4
0428	Arrocha	27	28	149	4/4
0429	Bossa Nova	27	29	144	4/4
0430	Forro 1	27	33	94	4/4
0431	Forro 2	27	34	76	4/4
0432	Forro 3	27	35	83	4/4
0433	Xote	27	46	84	4/4
0434	Vanerao	27	45	123	4/4
0435	Chamame	27	31	141	3/4
TRADIT / WORLD					
0436	Club Reggae	75	22	93	4/4
0437	Popshanty	75	23	105	4/4
0438	Lazy Reggae	8	6	88	4/4
0439	Love Reggae	8	7	120	4/4
0440	Reggae	8	8	96	4/4
0441	Island	8	10	105	4/4
0442	Ska	67	4	125	4/4
0443	Gospel Shuffle	44	34	210	4/4
0444	Pop Gospel	44	33	84	4/4
0445	2000's Bolero	55	3	102	4/4
0446	Western Movie	4	38	150	4/4
0447	Epic Movie	4	37	124	4/4
0448	Irish	67	3	120	4/4

No.	Name	CC00	CC32	BPM	TS
0449	Orchestr SI Fox	50	84	78	4/4
0450	Pop Fox	50	86	85	4/4
0451	Fox Band	50	87	176	4/4
0452	Foxtrot	34	7	185	4/4
0453	Country Fox	50	82	178	4/4
0454	Southern Twang	19	32	177	4/4
0455	Country Flyer	16	26	122	4/4
0456	Steamtrain Countr	16	25	144	2/4
0457	Slow Country	16	20	76	4/4
0458	Country Ballad	16	19	116	4/4
0459	Country Rock	16	15	135	4/4
0460	Country Beat	16	16	130	4/4
0461	Easy Country	16	17	170	4/4
0462	Country Pop	50	85	188	4/4
0463	Country Swing	16	18	190	4/4
0464	German Polka	19	29	106	4/4
0465	Posaunenpolka	19	31	132	4/4
0466	Slow Polka	19	28	100	4/4
0467	Orchestral Polka	19	9	128	4/4
0468	Austrian Polka	19	27	142	4/4
0469	Austrian Waltz	17	47	185	3/4
0470	Posaunenwalzer	17	50	206	3/4
0471	Schlagerwalzer	17	51	90	3/4
0472	French Java	17	52	160	3/4
0473	Orchestral Waltz	17	48	200	3/4
0474	Simple SI Waltz	18	10	85	3/4
0475	Orch SI Waltz	18	11	90	3/4
0476	Classic W'Waltz	17	24	185	6/4
0477	Guitar Waltz	18	13	110	3/4
0478	Classic	5	40	95	4/4
0479	6_8 March	20	11	120	4/4
0480	US March	20	10	120	4/4
0481	HU Beat	16	53	134	4/4
0482	HU Csardas	16	54	123	4/4
0483	HU Disco	16	55	160	4/4
0484	HU Discofox	16	56	136	4/4
0485	HU Latin-pop1	16	57	113	4/4
0486	HU Latin-pop2	16	58	113	4/4
0487	HU Mulatos	16	59	136	4/4
0488	HU Polka	16	60	130	4/4
0489	HU Ragga	16	61	104	4/4
0490	HU Rock & Roll	16	62	182	4/4
0491	HU Roma kv	16	63	103	4/4
0492	HU Twist	16	64	172	4/4
0493	PL Brathanki	16	65	168	4/4
0494	PL Dance Hit	16	66	131	4/4
0495	PL Disco Polka	16	67	140	4/4
0496	PL Dziew 6-8	16	68	106	6/8
0497	PL GroovRock	16	69	97	4/4
0498	PL Laendler	16	70	208	3/4
0499	PL Polka	16	71	124	4/4

No.	Name	CC00	CC32	BPM	TS
0500	PL Swing	16	72	202	4/4
0501	PL Tango	16	73	123	4/4
0502	PL WiosnaDnc	16	74	128	4/4
0503	SRB 7-8	16	75	130	7/8
0504	SRB 9-8	16	76	178	9/8
0505	SRB Dvojka	16	77	90	4/4
0506	SRB Rumba	16	78	110	4/4
0507	SRB Tamburasi 2-4	16	79	95	2/4
0508	Deepchandi	16	33	120	7/4
0509	Filmy Masti	16	34	120	4/4
0510	Garba	16	35	120	4/4
0511	Goa Masti	16	36	120	4/4
0512	Gujrati Pop	16	37	120	4/4
0513	Kaharva	16	38	120	4/4
0514	Lavani Guddu	16	39	120	4/4
0515	Marathi	16	40	120	4/4
0516	Punjabi	16	41	120	4/4
0517	Roopak	16	42	120	7/4
0518	Sam e Gazal	16	43	120	4/4
0519	Sindhi Lada	16	44	120	4/4
0520	South Indian	16	45	120	4/4
0521	South Masti	16	46	120	4/4
0522	Melayu	16	93	140	4/4
0523	Pop Indonesia	16	94	77	4/4
0524	DangdutKoplo	16	47	140	4/4
0525	DangdutStd	16	48	150	4/4
0526	Kolintang	16	49	122	4/4
0527	PopKeroncong	16	50	71	4/4
0528	PopMinang	16	51	122	4/4
0529	PopSunda	16	52	98	4/4
0530	ThaiChaCha	16	89	134	4/4
0531	I'SanChaCha 1	16	81	126	4/4
0532	I'SanChaCha 2	16	82	122	4/4
0533	ThaiOffBeat	16	90	106	4/4
0534	Guaracha	16	80	172	4/4
0535	Rumwong	16	84	172	4/4
0536	I'SanRumwong	16	83	100	4/4
0537	Serng	16	85	70	4/4
0538	SlowRumwong	16	86	98	4/4
0539	TaLoong	16	88	168	4/4
0540	SongMai	16	87	74	4/4

Recalling a Rhythm and a division via MIDI

The following program change numbers allow you to select the desired rhythm division via MIDI.

These messages need to be transmitted on the BK-9's rhythm channel.

If you also need to select a different rhythm, be sure to insert the corresponding CC00 and CC32 bank select values before one of the program changes shown below.

Rhythm Division	PC
INTRO 1	67
INTRO 2	68
INTRO 3	65
INTRO 4	66
MAIN 1	01
MAIN 2	02
MAIN 3	09
MAIN 4	10
FILL DOWN 1	89
FILL DOWN 2	100
FILL DOWN 3	90
FILL UP 1	97
FILL UP 2	99
FILL UP 3	98
ENDING 1	75
ENDING 2	76
ENDING 3	73
ENDING 4	74

E-Series compatibility

Rhythm Division	PC
INTRO	83
FILL IN TO ORIGINAL	82
FILL IN TO VARIATION	81
ENDING	84
BREAK MUTE	85

Roland

602.00.0598 RES 944-13 BK-9 Rhythm List



602000598