

# Roland E-09 MIDI Implementation

Model: E-09  
Date: July, 1, 2008  
Version: 1.00

## 1. Receive data

### ■ Channel Voice Messages

#### ● Note off

Status	2nd byte	3rd byte
8nH	kkH	vvH
9nH	kkH	00H

n = MIDI channel number: 0H - FH (ch.1 - 16)

kk = note number: 00H - 7FH (0 - 127)

vv = note off velocity: 00H - 7FH (0 - 127)

- \* For Drum Parts, these messages are received when Rx.NOTE OFF = ON for each Instrument.
- \* The velocity values of Note Off messages are ignored.

#### ● Note on

Status	2nd byte	3rd byte
9nH	kkH	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

kk = note number: 00H - 7FH (0 - 127)

vv = note on velocity: 01H - 7FH (1 - 127)

- \* Not received when Rx.NOTE MESSAGE = OFF. (Initial value is ON)
- \* For Drum Parts, these messages are not received when Rx.NOTE ON = OFF for each Instrument.

### ● Control Change

- \* When Rx.CONTROL CHANGE = OFF, all control change messages except for Channel Mode messages will be ignored.
- \* The value specified by a Control Change message will not be reset even by a Program Change, etc.

#### ○ Bank Select (Controller number 0, 32)

Status	2nd byte	3rd byte
BnH	00H	mmH
BnH	20H	llH

n = MIDI channel number: 0H - FH (ch.1 - 16)

mm, ll = Bank number: 00 00H - 7F 7FH (bank.1 - bank.16384), Initial value = 00 00H

- \* Not received when Function: Prog Change = OFF. (Initial value is ON)
- \* Not received when Rx.BANK SELECT = OFF.
- \* Rx.BANK SELECT is set to OFF by GM1 System On, and Bank Select messages will be ignored.
- \* Rx.BANK SELECT is set to ON by GM2 System On.
- \* Rx.BANK SELECT is set to ON by power-on reset or by receiving GS Reset.
- \* When Rx.BANK SELECT LSB = OFF, Bank number LSB (llH) will be handled as 00H regardless of the received value. However, when sending Bank Select messages, you have to send both the MSB (mmH) and LSB (llH, the value should be 00H) together.
- \* Bank Select processing will be suspended until a Program Change message is received.
- \* The GS format "Variation number" is the value of the Bank Select MSB (Controller number 0) expressed in decimal.
- \* Some other GS devices do not recognize the Bank Select LSB (Controller number 32).

BANK MSB	SELECT LSB	PROGRAM NUMBER	GROUP
000	000 -	001 - 128	Tone/Drum Set/Style
120	000	001 - 057	GM2 Drum Set
121	000 -	001 - 128	GM2 Tone

#### ○ Modulation (Controller number 1)

Status	2nd byte	3rd byte
BnH	01H	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Modulation depth: 00H - 7FH (0 - 127)

- \* Not received when Function: Modulation = OFF. (Initial value is ON)
- \* Not received when Rx.MODULATION = OFF (Initial value is ON)
- \* The resulting effect is determined by System Exclusive messages. With the initial settings, this is Pitch Modulation Depth.

#### ○ Portamento Time (Controller number 5)

Status	2nd byte	3rd byte
BnH	05H	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Portamento Time: 00H - 7FH (0 - 127), Initial value = 00H (0)

- \* This adjusts the rate of pitch change when Portamento is ON or when using the Portamento Control. A value of 0 results in the fastest change.

#### ○ Data Entry (Controller number 6, 38)

Status	2nd byte	3rd byte
BnH	06H	mmH
BnH	26H	llH

n = MIDI channel number: 0H - FH (ch.1 - 16)

mm, ll = the value of the parameter specified by RPN/NRPN

mm = MSB, ll = LSB

#### ○ Volume (Controller number 7)

Status	2nd byte	3rd byte
BnH	07H	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Volume: 00H - 7FH (0 - 127), Initial value = 64H (100)

- \* Volume messages are used to adjust the volume balance of each Part.
- \* Not received when Rx.VOLUME = OFF. (Initial value is ON)

#### ○ Panpot (Controller number 10)

Status	2nd byte	3rd byte
BnH	0AH	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Panpot: 00H - 40H - 7FH (Left - Center - Right), Initial value = 40H (Center)

- \* For Rhythm Parts, this is a relative adjustment of each Instrument's pan setting.
- \* Not received when Rx.PANPOT = OFF. (Initial value is ON)

#### ○ Expression (Controller number 11)

Status	2nd byte	3rd byte
BnH	0BH	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Expression: 00H - 7FH (0 - 127), Initial value = 7FH (127)

- \* This adjusts the volume of a Part. It can be used independently from Volume messages. Expression messages are used for musical expression within a performance; e.g., expression pedal movements, crescendo and decrescendo.
- \* Not received when Rx.EXPRESSION = OFF. (Initial value is ON)

#### ○ Hold 1 (Controller number 64)

Status	2nd byte	3rd byte
BnH	40H	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Control value: 00H - 7FH (0 - 127)

- \* Not received when Rx.HOLD1 = OFF. (Initial value is ON)

#### ○ Portamento (Controller number 65)

Status	2nd byte	3rd byte
BnH	41H	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Control value: 00H - 7FH (0 - 127) 0 - 63 = OFF, 64 - 127 = ON

- \* Not received when Rx.PORTAMENTO = OFF. (Initial value is ON)

# Roland E-09 MIDI Implementation

## ○Sostenuto (Controller number 66)

Status	2nd byte	3rd byte
BnH	42H	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Control value: 00H - 7FH (0 - 127) 0 - 63 = OFF, 64 - 127 = ON

\* Not received when Rx.SOSTENUTO = OFF. (Initial value is ON)

## ○Soft (Controller number 67)

Status	2nd byte	3rd byte
BnH	43H	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Control value: 00H - 7FH (0 - 127) 0 - 63 = OFF, 64 - 127 = ON

\* Not received when Rx.SOFT = OFF. (Initial value is ON)

## ○Filter Resonance (Timbre/Harmonic Intensity) (Controller number 71)

Status	2nd byte	3rd byte
BnH	47H	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Resonance value (relative change): 00H - 40H - 7FH (-64 - 0 - +63), Initial value = 40H (no change)

## ○Release Time (Controller number 72)

Status	2nd byte	3rd byte
BnH	48H	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Release Time value (relative change): 00H - 40H - 7FH (-64 - 0 - +63), Initial value = 40H (no change)

## ○Attack time (Controller number 73)

Status	2nd byte	3rd byte
BnH	49H	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Attack time value (relative change): 00H - 40H - 7FH (-64 - 0 - +63), Initial value = 40H (no change)

## ○Cutoff (Controller number 74)

Status	2nd byte	3rd byte
BnH	4AH	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Cutoff value (relative change): 00H - 40H - 7FH (-64 - 0 - +63), Initial value = 40H (no change)

## ○Decay Time (Controller number 75)

Status	2nd byte	3rd byte
BnH	4BH	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Decay Time value (relative change): 00H - 40H - 7FH (-64 - 0 - +63), Initial value = 40H (no change)

## ○Vibrato Rate (Controller number 76)

Status	2nd byte	3rd byte
BnH	4CH	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Vibrato Rate value (relative change): 00H - 40H - 7FH (-64 - 0 - +63), Initial value = 40H (no change)

## ○Vibrato Depth (Controller number 77)

Status	2nd byte	3rd byte
BnH	4DH	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Vibrato Depth Value (relative change): 00H - 40H - 7FH (-64 - 0 - +63), Initial value = 40H (no change)

## ○Vibrato Delay (Controller number 78)

Status	2nd byte	3rd byte
BnH	4EH	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Vibrato Delay value (relative change): 00H - 40H - 7FH (-64 - 0 - +63), Initial value = 40H (no change)

## ○Portamento control (Controller number 84)

Status	2nd byte	3rd byte
BnH	54H	kkH

n = MIDI channel number: 0H - FH (ch.1 - 16)

kk = source note number: 00H - 7FH (0 - 127)

- \* A Note-on received immediately after a Portamento Control message will change continuously in pitch, starting from the pitch of the Source Note Number.
- \* If a voice is already sounding for a note number identical to the Source Note Number, this voice will continue sounding (i.e., legato) and will, when the next Note-on is received, smoothly change to the pitch of that Note-on.
- \* The rate of the pitch change caused by Portamento Control is determined by the Portamento Time value.

Example 1.

On MIDI	Description	Result
90 3C 40	Note on C4	C4 on
B0 54 3C	Portamento Control from C4	no change
90 40 40	Note on E4	glide from C4 to E4
80 3C 40	Note off C4	no change
80 40 40	Note off E4	E4 off

Example 2.

On MIDI	Description	Result
B0 54 3C	Portamento Control from C4	no change
90 40 40	Note on E4	E4 is played with a glide from C4 to E4
80 40 40	Note off E4	E4 off

## ○Effect 1 (Reverb Send Level) (Controller number 91)

Status	2nd byte	3rd byte
BnH	5BH	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Reverb Send Level: 00H - 7FH (0 - 127), Initial value = 28H (40)

\* This message adjusts the Reverb Send Level of each Part.

## ○Effect 3 (Chorus Send Level) (Controller number 93)

Status	2nd byte	3rd byte
BnH	5DH	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Chorus Send Level: 00H - 7FH (0 - 127), Initial value = 00H (0)

\* This message adjusts the Chorus Send Level of each Part.

## ○NRPN MSB/LSB (Controller number 99, 98)

Status	2nd byte	3rd byte
BnH	63H	mmH
BnH	62H	llH

n = MIDI channel number: 0H - FH (ch.1 - 16)

mm = upper byte (MSB) of parameter number specified by NRPN

ll = lower byte (LSB) of parameter number specified by NRPN

\* Rx.NRPN is set to OFF by power-on reset or by receiving "GM1 System On" or "GM2 System On," and NRPN message will be ignored. NRPN message will be received when Rx.NRPN = ON, or by receiving GS RESET.

\* The value set by NRPN will not be reset even if Program Change or Reset All Controllers is received.

### \*\*NRPN\*\*

The NRPN (Non Registered Parameter Number) message allows an extended range of control changes to be used. On the E-09, NRPN messages can be used to modify sound parameters, etc.

To use these messages, you must first use NRPN messages (Controller number 98 and 99, their order does not matter) to specify the parameter to be controlled, and then use Data

# Roland E-09 MIDI Implementation

Entry messages (Controller number 6) to specify the value of the specified parameter. Once an NRPN parameter has been specified, all Data Entry messages received on that channel will modify the value of that parameter. To prevent accidents, it is recommended that you set RPN Null (RPN Number = 7FH 7FH) when you have finished setting the value of the desired parameter. Refer to "5. Supplementary material", Examples of actual MIDI messages [Example 4] (p. 18). On the E-09, Data entry LSB (Controller number 38) of NRPN is ignored, so it is no problem to send Data entry MSB (Controller number 6) only (without Data entry LSB).

On the E-09, NRPN can be used to modify the following parameters.

NRPN	Data entry	
<u>MSB LSB</u>	<u>MSB</u>	<u>Function and range</u>
01H 08H	mmH	Vibrato Rate (relative change) mm: 00H - 40H - 7FH (-64 - 0 - +63)
01H 09H	mmH	Vibrato Depth (relative change) mm: 00H - 40H - 7FH (-64 - 0 - +63)
01H 0AH	mmH	Vibrato Delay (relative change) mm: 00H - 40H - 7FH (-64 - 0 - +63)
01H 20H	mmH	TVF Cutoff Frequency (relative change) mm: 00H - 40H - 7FH (-64 - 0 - +63)
01H 21H	mmH	TVF Resonance (relative change) mm: 00H - 40H - 7FH (-64 - 0 - +63)
01H 63H	mmH	TVF&TVA Envelope Attack Time (relative change) mm: 00H - 40H - 7FH (-64 - 0 - +63)
01H 64H	mmH	TVF&TVA Envelope Decay Time (relative change) mm: 00H - 40H - 7FH (-64 - 0 - +63)
01H 66H	mmH	TVF&TVA Envelope Release Time (relative change) mm: 00H - 40H - 7FH (-64 - 0 - +63)
18H rrH	mmH	Drum Instrument Pitch Coarse (relative change) rr: Drum Instrument note number mm: 00H - 40H - 7FH (-64 - 0 - +63 semitone)
1AH rrH	mmH	Drum Instrument TVA Level (absolute change) rr: Drum Instrument note number mm: 00H - 7FH (0 - max)
1CH rrH	mmH	Drum Instrument Panpot (absolute change) rr: Drum Instrument note number mm: 00H, 01H - 40H - 7FH (random, left - center - right)
1DH rrH	mmH	Drum Instrument Reverb Send Level (absolute change) rr: Drum Instrument note number mm: 00H - 7FH (0 - max)
1EH rrH	mmH	Drum Instrument Chorus Send Level (absolute change) rr: Drum Instrument note number mm: 00H - 7FH (0 - max)

- \* Parameters marked "relative change" will change relatively to the preset value(40H). Even among different GS devices, "relative change" parameters may sometimes differ in the way the sound changes or in the range of change.
- \* Parameters marked "absolute change" will be set to the absolute value of the parameter, regardless of the preset value.
- \* Data entry LSB (llH) is ignored.

## ORPN MSB/LSB (Controller number 101, 100)

Status	2nd byte	3rd byte
BnH	65H	mmH
BnH	64H	llH

n = MIDI channel number: 0H - FH (ch.1 - 16)

mm = upper byte (MSB) of parameter number specified by RPN

ll = lower byte (LSB) of parameter number specified by RPN

- \* Not received when Rx.RPN = OFF.
- \* The value specified by RPN will not be reset even by messages such as Program Change or Reset All Controller.

## \*\*RPN\*\*

The RPN (Registered Parameter Number) messages are expanded control changes, and each function of an RPN is described by the MIDI Standard.

To use these messages, you must first use RPN (Controller number 100 and 101, their order does not matter) to specify the parameter to be controlled, and then use Data Entry messages (Controller number 6, 38) to specify the value of the specified parameter. Once an RPN parameter has been specified, all Data Entry messages received on that channel will modify the value of that parameter. To prevent accidents, it is recommended that you set RPN Null (RPN Number = 7FH 7FH) when you have finished setting the value of the desired parameter. Refer to "5. Supplementary material", Examples of actual MIDI messages [Example 4] (p. 18).

On the E-09, RPN can be used to modify the following parameters.

RPN	Data entry	
<u>MSB LSB</u>	<u>MSB LSB</u>	<u>Function and range</u>
00H 00H	mmH llH	Pitch Bend Sensitivity mm: 00H - 18H (0 - 24 semitones), Initial value = 02H (2 semitones) ll: ignored (processed as 00H) specify up to 2 octaves in semitone steps.
00H 01H	mmH llH	Channel Fine Tuning mm, ll: 00 00H - 40 00H - 7F 7FH (-100 - 0 - +99.99 cents), Initial value = 40 00H (+/- 0 cent) Refer to "5. Supplementary material", About the Tuning (p. 19).
00H 02H	mmH llH	Channel Coarse Tuning mm: 28H - 40H - 58H (-24 - 0 - +24 semitones), Initial value = 40H (+/- 0 semitone) ll: ignored (processed as 00H)
00H 05H	mmH llH	Modulation Depth Range mm: 00H - 04H (0 - 4 semitones) ll: 00H - 7FH (0 - 100 cents), 100/128 Cent/Value
7FH 7FH	---	RPN null Set condition where RPN and NRPN are unspecified. The data entry messages after set RPN null will be ignored. (No Data entry messages are required after RPN null). Settings already made will not change. mm, ll: ignored

## ●Program Change

Status	2nd byte
CnH	ppH

n = MIDI channel number: 0H - FH (ch.1 - 16)

pp = Program number: 00H - 7FH (prog.1 - prog.128)

- \* Not received when Function: Prog Change = OFF. (Initial value is ON)
- \* Not received when Rx.PROGRAM CHANGE = OFF. (Initial value is ON)

## ●Channel Pressure

Status	2nd byte
DnH	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)

vv = Channel Pressure: 00H - 7FH (0 - 127)

- \* Not received when Rx.CH PRESSURE (CAf) = OFF. (Initial value is ON)
- \* The resulting effect is determined by System Exclusive messages. With the initial settings there will be no effect.

## ●Pitch Bend Change

Status	2nd byte	3rd byte
EnH	llH	mmH

n = MIDI channel number: 0H - FH (ch.1 - 16)

mm, ll = Pitch Bend value: 00 00H - 40 00H - 7F 7FH (-8192 - 0 - +8191)

- \* Not received when Function: Pitch Bend = OFF. (Initial value is ON)
- \* Not received when Rx.PITCH BEND = OFF. (Initial value is ON)
- \* The resulting effect is determined by System Exclusive messages. With the initial settings the effect is Pitch Bend.

## ■Channel Mode Messages

### ●All Sounds Off (Controller number 120)

Status	2nd byte	3rd byte
BnH	78H	00H

n = MIDI channel number: 0H - FH (ch.1 - 16)

- \* When this message is received, all currently sounding notes on the corresponding channel will be turned off immediately.

# Roland E-09 MIDI Implementation

## ●Reset All Controllers (Controller number 121)

Status	2nd byte	3rd byte
BnH	79H	00H

n = MIDI channel number: 0H - FH (ch.1 - 16)

\* When this message is received, the following controllers will be set to their reset values.

Controller	Reset value
Pitch Bend Change	+/-0 (center)
Polyphonic Key Pressure	0 (off)
Channel Pressure	0 (off)
Modulation	0 (off)
Expression	127 (max)
Hold 1	0 (off)
Portamento	0 (off)
Sostenuto	0 (off)
Soft	0 (off)
RPN	unset; previously set data will not change
NRPN	unset; previously set data will not change

## ●All Notes Off (Controller number 123)

Status	2nd byte	3rd byte
BnH	7BH	00H

n = MIDI channel number: 0H - FH (ch.1 - 16)

\* When All Notes Off is received, all notes on the corresponding channel will be turned off. However, if Hold 1 or Sostenuto is ON, the sound will be continued until these are turned off.

## ●OMNI OFF (Controller number 124)

Status	2nd byte	3rd byte
BnH	7CH	00H

n = MIDI channel number: 0H - FH (ch.1 - 16)

\* The same processing will be carried out as when All Notes Off is received.

## ●OMNI ON (Controller number 125)

Status	2nd byte	3rd byte
BnH	7DH	00H

n = MIDI channel number: 0H - FH (ch.1 - 16)

\* The same processing will be carried out as when All Notes Off is received. OMNI ON will not be turned on.

## ●MONO (Controller number 126)

Status	2nd byte	3rd byte
BnH	7EH	mmH

n = MIDI channel number: 0H - FH (ch.1 - 16)

mm = mono number: 00H - 10H (0 - 16)

\* The same processing will be carried out as when All Sounds Off and All Notes Off is received, and the corresponding channel will be set to Mode 4 (M = 1) regardless of the value of "mm (mono number)".

## ●POLY (Controller number 127)

Status	2nd byte	3rd byte
BnH	7FH	00H

n = MIDI channel number: 0H - FH (ch.1 - 16)

\* The same processing will be carried out as when All Sounds Off and All Notes Off is received, and the corresponding channel will be set to Mode 3.

## ■System Realtime Messages

### ●Timing Clock

Status
F8H

\* When "Timing Clock" is received, the internal song/style player is synchronized to an external clock according to the following table.

Function: Sync Rx	Response
OFF (Internal)	A Song/Style will neither start/stop nor follow the tempo of the external "Timing Clock" (F8) and "Start/Stop" (FA/FC) messages.
ON (Auto)	If a Song/Style receives "Start/Stop" (FA/FC), it will follow automatically Internal or External Timing related to the presence or not of the incoming "Timing Clock" (F8) messages.

### ●Song/Style Start

Status
FAH

\* When "Start" is received, the internal song/style player start.

### ●Song Continue

Status
FBH

\* When "Continue" is received, the internal song player continue to play from the current position.

\* Received only in Song Mode.

### ●Song/Style Stop

Status
FCH

\* When "Stop" is received, the internal song/style player stop.

### ●Active Sensing

Status
FEH

\* When "Active Sensing" is received, the unit will begin monitoring the intervals of all further messages. While monitoring, if the interval between messages exceeds 420 ms, the same processing will be carried out as when All Sounds Off, All Notes Off and Reset All Controllers are received, and message interval monitoring will be halted.

## ■System Common Message

### ●Song Position Pointer

Status	2nd byte	3rd byte
F2H	llH	hhH

ll = song position LSB: 00H - 7FH

hh = song position MSB: 00H - 7FH

\* Received only in Song Mode.

## ■System Exclusive Messages

Status	Data byte	Status
F0H	iiH, ddH, .....eeH	F7H

F0H: System Exclusive Message status

ii = ID number: an ID number (manufacturer ID) to indicate the manufacturer whose Exclusive message this is. Roland's manufacturer ID is 41H.

ID numbers 7EH and 7FH are extensions of the MIDI standard; Universal Non-realtime Messages (7EH) and Universal Realtime Messages (7FH).

dd,....,ee = data: 00H - 7FH (0 - 127)

F7H: EOX (End Of Exclusive)

The System Exclusive messages received by the E-09 are: messages related to mode settings, Universal Realtime System Exclusive messages and Data Set (DT1).

## ●System Exclusive messages related to mode settings

These messages are used to initialize a device to GS or General MIDI mode, or change the operating mode. When creating performance data, a “GM1 System On” message should be inserted at the beginning of a General MIDI 1 score, a “GM2 System On” message at the beginning of a General MIDI 2 score, and a “GS Reset” message at the beginning of a GS music data. Each song should contain only one mode message as appropriate for the type of data. (Do not insert two or more mode setting messages in a single song.) “GM System On” uses Universal Non-realtime Message format. “GS Reset” uses Roland System Exclusive format “Data Set 1 (DT1)”.

### ○GM1 System On

“GM1 System On” is a command message that resets the internal settings of the unit to the General MIDI 1 initial state. After receiving this message, the E-09 will automatically be set to the proper condition for correctly playing a General MIDI 1 score.

Status	Data byte	Status
F0H	7EH, 7FH, 09H, 01H	F7H

Byte	Explanation
F0H	Exclusive status
7EH	ID number (Universal Non-realtime Message)
7FH	Device ID (Broadcast)
09H	Sub ID#1 (General MIDI Message)
01H	Sub ID#2 (General MIDI 1 On)
F7H	EOX (End Of Exclusive)

- \* When this message is received, Rx.BANK SELECT will be OFF and Rx.NRPN will be OFF.
- \* There must be an interval of at least 50 ms between this message and the next.

### ○GM2 System On

“GM2 System On” is a command message that resets the internal settings of the unit to the General MIDI 2 initial state. After receiving this message, the E-09 will automatically be set to the proper condition for correctly playing a General MIDI 2 score.

Status	Data byte	Status
F0H	7EH, 7FH, 09H, 03H	F7H

Byte	Explanation
F0H	Exclusive status
7EH	ID number (Universal Non-realtime Message)
7FH	Device ID (Broadcast)
09H	Sub ID#1 (General MIDI Message)
03H	Sub ID#2 (General MIDI 2 On)
F7H	EOX (End Of Exclusive)

- \* When this message is received, the E-09 will be able to receive the messages specified by General MIDI 2, and use the General MIDI 2 sound map.
- \* There must be an interval of at least 50 ms between this message and the next.

### ○GM System Off

“GM System Off” is a command message that resets the internal state of the E-09 from the GM state to its native condition.

Status	Data byte	Status
F0H	7EH, 7FH, 09H, 02H	F7H

Byte	Explanation
F0H	Exclusive status
7EH	ID number (Universal Non-realtime Message)
7FH	Device ID (Broadcast)
09H	Sub ID#1 (General MIDI Message)
02H	Sub ID#2 (General MIDI Off)
F7H	EOX (End Of Exclusive)

- \* When this messages is received, the E-09 will reset to the GS default state.
- \* There must be an interval of at least 50 ms between this message and the next.

### ○GS Reset

“GS Reset” is a command message that resets the internal settings of the E-09 to the GS initial state. This message appears at the beginning of GS music data, and a GS device that receives this message will automatically be set to the proper state to correctly play back GS music data.

Status	Data byte	Status
F0H	41H, dev, 42H, 12H, 40H, 00H, 7FH, 00H, 41H	F7H

Byte	Explanation
F0H	Exclusive status
41H	ID number (Roland)
dev	Device ID (dev: 00H - 1FH (1 - 32), Initial value is 10H (17))
42H	Model ID (GS)
12H	Command ID (DT1)
40H	Address MSB
00H	Address
7FH	Address LSB
00H	Data (GS reset)
41H	Checksum
F7H	EOX (End Of Exclusive)

- \* When this message is received, Rx.NRPN will be ON.
- \* There must be an interval of at least 50 ms between this message and the next.

## ●Universal Non-realtime System Exclusive Message

### ○Identity Request Message

Status	Data byte	Status
F0H	7EH, dev, 06H, 01H	F7H

Byte	Explanation
F0H	Exclusive status
7EH	ID number (Universal Non-realtime Message)
dev	Device ID (dev: 10H - 1FH, 7FH)
06H	Sub ID#1 (General Information)
01H	Sub ID#2 (Identity Request)
F7H	EOX (End Of Exclusive)

- \* When this message is received, Identity Reply message will be transmitted.

## ●Universal Realtime System Exclusive Messages

### ○Master Volume

Status	Data byte	Status
F0H	7FH, 7FH, 04H, 01H, lH, mmH	F7H

Byte	Explanation
F0H	Exclusive status
7FH	ID number (universal realtime message)
7FH	Device ID (Broadcast)
04H	Sub ID#1 (Device Control)
01H	Sub ID#2 (Master Volume)
lH	Master Volume lower byte
mmH	Master Volume upper byte
F7H	EOX (End Of Exclusive)

- \* The lower byte (lH) of Master Volume will be handled as 00H.

### ○Master Fine Tuning

Status	Data byte	Status
F0H	7FH, 7FH, 04H, 03H, lH, mmH	F7H

Byte	Explanation
F0H	Exclusive status
7FH	ID number (universal realtime message)
7FH	Device ID (Broadcast)
04H	Sub ID#1 (Device Control)
03H	Sub ID#2 (Master Fine Tuning)
lH	Master Fine Tuning LSB
mmH	Master Fine Tuning MSB
F7H	EOX (End Of Exclusive)

mm, l: 00 00H - 40 00H - 7F 7FH (-100 - 0 - +99.9 [cents])

### ○Master Coarse Tuning

Status	Data byte	Status
F0H	7FH, 7FH, 04H, 04H, lH, mmH	F7

Byte	Explanation
F0H	Exclusive status
7FH	ID number (universal realtime message)
7FH	Device ID (Broadcast)
04H	Sub ID#1 (Device Control)
04H	Sub ID#2 (Master Coarse Tuning)
lH	Master Coarse Tuning LSB

# Roland E-09 MIDI Implementation

mmH Master Coarse Tuning MSB  
F7H EOX (End Of Exclusive)

llH: ignored (processed as 00H)  
mmH: 28H - 40H - 58H (-24 - 0 - +24 [semitones])

## ●Global Parameter Control

### ○Reverb Parameters

Status	Data byte	Status
F0H	7FH, 7FH, 04H, 05H, 01H, 01H, 01H, 01H, 01H, ppH, vvH	F7H

Byte	Explanation
F0H	Exclusive status
7FH	ID number (universal realtime message)
7FH	Device ID (Broadcast)
04H	Sub ID#1 (Device Control)
05H	Sub ID#2 (Global Parameter Control)
01H	Slot path length
01H	Parameter ID width
01H	Value width
01H	Slot path MSB
01H	Slot path LSB (Effect 0101: Reverb)
ppH	Parameter to be controlled.
vvH	Value for the parameter.
F7H	EOX (End Of Exclusive)

pp=0 Reverb Type  
vv = 00H Small Room (ROOM 1)  
vv = 01H Medium Room (ROOM 2)  
vv = 02H Large Room (ROOM 3)  
vv = 03H Medium Hall (HALL 1)  
vv = 04H Large Hall (HALL 2)  
vv = 08H Plate (PLATE)

pp=1 Reverb Time  
vv = 00H - 7FH 0 - 127

### ○Chorus Parameters

Status	Data byte	Status
F0H	7FH, 7FH, 04H, 05H, 01H, 01H, 01H, 01H, 02H, ppH, vvH	F7H

Byte	Explanation
F0H	Exclusive status
7FH	ID number (universal realtime message)
7FH	Device ID (Broadcast)
04H	Sub ID#1 (Device Control)
05H	Sub ID#2 (Global Parameter Control)
01H	Slot path length
01H	Parameter ID width
01H	Value width
01H	Slot path MSB
02H	Slot path LSB (Effect 0102: Chorus)
ppH	Parameter to be controlled.
vvH	Value for the parameter.
F7H	EOX (End Of Exclusive)

pp=0 Chorus Type  
vv=0 Chorus1 (CHORUS 1)  
vv=1 Chorus2 (CHORUS 2)  
vv=2 Chorus3 (CHORUS 3)  
vv=3 Chorus4 (CHORUS 4)  
vv=4 FB Chorus (FB CHORUS)  
vv=5 Flanger (FLANGER)

pp=1 Mod Rate  
vv = 00H - 7FH 0 - 127

pp=2 Mod Depth  
vv = 00H - 7FH 0 - 127

pp=3 Feedback  
vv = 00H - 7FH 0 - 127

pp=4 Send To Reverb  
vv = 00H - 7FH 0 - 127

### ○Channel Pressure

Status	Data byte	Status
F0H	7FH, 7FH, 09H, 01H, 0nH, ppH, rrH	F7H

Byte	Explanation
F0H	Exclusive status
7FH	ID number (universal realtime message)
7FH	Device ID (Broadcast)
09H	Sub ID#1 (Controller Destination Setting)
01H	Sub ID#2 (Channel Pressure)
0nH	MIDI Channel (00 - 0F)
ppH	Controlled parameter
rrH	Controlled range
F7H	EOX (End Of Exclusive)

pp=0 Pitch Control  
rr = 28H - 58H -24 - +24 [semitones]

pp=1 Filter Cutoff Control  
rr = 00H - 7FH -9600 - +9450 [cents]

pp=2 Amplitude Control  
rr = 00H - 7FH 0 - 200%

pp=3 LFO Pitch Depth  
rr = 00H - 7FH 0 - 600 [cents]

pp=4 LFO Filter Depth  
rr = 00H - 7FH 0 - 2400 [cents]

pp=5 LFO Amplitude Depth  
rr = 00H - 7FH 0 - 100%

### ○Controller

Status	Data byte	Status
F0H	7FH, 7FH, 09H, 03H, 0nH, ccH, ppH, rrH	F7H

Byte	Explanation
F0H	Exclusive status
7FH	ID number (universal realtime message)
7FH	Device ID (Broadcast)
09H	Sub ID#1 (Controller Destination Setting)
03H	Sub ID#2 (Control Change)
0nH	MIDI Channel (00 - 0F)
ccH	Controller number (01 - 1F, 40 - 5F)
ppH	Controlled parameter
rrH	Controlled range
F7H	EOX (End Of Exclusive)

pp=0 Pitch Control  
rr = 28H - 58H -24 - +24 [semitones]

pp=1 Filter Cutoff Control  
rr = 00H - 7FH -9600 - +9450 [cents]

pp=2 Amplitude Control  
rr = 00H - 7FH 0 - 200%

pp=3 LFO Pitch Depth  
rr = 00H - 7FH 0 - 600 [cents]

pp=4 LFO Filter Depth  
rr = 00H - 7FH 0 - 2400 [cents]

pp=5 LFO Amplitude Depth  
rr = 00H - 7FH 0 - 100%

### ○Scale/Octave Tuning Adjust

Status	Data byte	Status
F0H	7EH, 7FH, 08H, 08H, ffH, ggH, hhH, ssH...	F7

Byte	Explanation
F0H	Exclusive status
7EH	ID number (Universal Non-realtime Message)
7FH	Device ID (Broadcast)
08H	Sub ID#1 (MIDI Tuning Standard)
08H	Sub ID#2 (scale/octave tuning 1-byte form)
ffH	Channel/Option byte 1 bits 0 to 1 = channel 15 to 16 bit 2 to 6 = Undefined
ggH	Channel byte 2 bits 0 to 6 = channel 8 to 14
hhH	Channel byte 3 bits 0 to 6 = channel 1 to 7
ssH	12 byte tuning offset of 12 semitones from C to B 00H = -64 [cents] 40H = 0 [cents] (equal temperament) 7FH = +63 [cents]
F7H	EOX (End Of Exclusive)

## ○Key-based Instrument Controllers

Status	Data byte	Status
F0H	7FH, 7FH, 0AH, 01H, 0nH, kkH, nnH, vvH	F7H

Byte	Explanation
F0H	Exclusive status
7FH	ID number (universal realtime message)
7FH	Device ID (Broadcast)
0AH	Sub ID#1 (Key-Based Instrument Control)
01H	Sub ID#2 (Controller)
0nH	MIDI Channel (00 - 0FH)
kkH	Key Number
nnH	Control Number
vvH	Value
:	:
F7H	EOX (End Of Exclusive)

nn=07H Level	vv = 00H - 7FH	0 - 200% (Relative)
nn=0AH Pan	vv = 00H - 7FH	Left - Right (Absolute)
nn=5BH Reverb Send	vv = 00H - 7FH	0 - 127 (Absolute)
nn=5DH Chorus Send	vv = 00H - 7FH	0 - 127 (Absolute)

\* This parameter affects drum instruments only.

## 2. Transmit Data

### ■Channel Voice Messages

#### ●Note off

Status	2nd byte	3rd byte
9nH	kkH	00H

n = MIDI channel number: 0H - FH (ch.1 - 16)  
kk = note number: 00H - 7FH (0 - 127)

#### ●Note on

Status	2nd byte	3rd byte
9nH	kkH	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)  
kk = note number: 00H - 7FH (0 - 127)  
vv = note on velocity: 01H - 7FH (1 - 127)

#### ●Control Change

##### ○Bank Select (Controller number 0, 32)

Status	2nd byte	3rd byte
BnH	00H	mmH
BnH	20H	llH

n = MIDI channel number: 0H - FH (ch.1 - 16)  
mm, ll = Bank number: 00 00H - 7F 7FH (bank.1 - bank.16384)

\* Not transmitted when Function: Prog Change = OFF. (Initial value is ON)

##### ○Modulation (Controller number 1)

Status	2nd byte	3rd byte
BnH	01H	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)  
vv = Modulation depth: 00H - 7FH (0 - 127)

\* Not transmitted when Function: Modulation = OFF. (Initial value is ON)

##### ○Portamento Time (Controller number 5)

Status	2nd byte	3rd byte
BnH	05H	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)  
vv = Portamento Time: 00H - 7FH (0 - 127)

##### ○Data Entry (Controller number 6, 38)

Status	2nd byte	3rd byte
BnH	06H	mmH
BnH	26H	llH

n = MIDI channel number: 0H - FH (ch.1 - 16)  
mm, ll = the value of the parameter specified by RPN/NRPN  
mm = MSB, ll = LSB

##### ○Volume (Controller number 7)

Status	2nd byte	3rd byte
BnH	07H	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)  
vv = Volume: 00H - 7FH (0 - 127)

##### ○Panpot (Controller number 10)

Status	2nd byte	3rd byte
BnH	0AH	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)  
vv = Panpot: 00H - 40H - 7FH (Left - Center - Right)

##### ○Expression (Controller number 11)

Status	2nd byte	3rd byte
BnH	0BH	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)  
vv = Expression: 00H - 7FH (0 - 127)

##### ○Hold 1 (Controller number 64)

Status	2nd byte	3rd byte
BnH	40H	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)  
vv = Control value: 00H - 7FH (0 - 127)

##### ○Portamento (Controller number 65)

Status	2nd byte	3rd byte
BnH	41H	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)  
vv = Control value: 00H - 7FH (0 - 127) 0 - 63 = OFF, 64 - 127 = ON

##### ○Sostenuto (Controller number 66)

Status	2nd byte	3rd byte
BnH	42H	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)  
vv = Control value: 00H - 7FH (0 - 127) 0 - 63 = OFF, 64 - 127 = ON

##### ○Soft (Controller number 67)

Status	2nd byte	3rd byte
BnH	43H	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)  
vv = Control value: 00H - 7FH (0 - 127) 0 - 63 = OFF, 64 - 127 = ON

##### ○Portamento control (Controller number 84)

Status	2nd byte	3rd byte
BnH	54H	kkH

n = MIDI channel number: 0H - FH (ch.1 - 16)  
kk = source note number: 00H - 7FH (0 - 127)

##### ○Effect 1 (Reverb Send Level) (Controller number 91)

Status	2nd byte	3rd byte
BnH	5BH	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)  
vv = Reverb Send Level: 00H - 7FH (0 - 127)

# Roland E-09 MIDI Implementation

## ○Effect 3 (Chorus Send Level) (Controller number 93)

Status	2nd byte	3rd byte
BnH	5DH	vvH

n = MIDI channel number: 0H - FH (ch.1 - 16)  
 vv = Chorus Send Level: 00H - 7FH (0 - 127)

## ○NRPN MSB/LSB (Controller number 99, 98)

Status	2nd byte	3rd byte
BnH	63H	mmH
BnH	62H	llH

n = MIDI channel number: 0H - FH (ch.1 - 16)  
 mm = upper byte (MSB) of parameter number specified by NRPN  
 ll = lower byte (LSB) of parameter number specified by NRPN

### \*\*NRPN\*\*

The NRPN (Non Registered Parameter Number) message allows an extended range of control changes to be used, letting you use control functions which are not defined in the MIDI Specification.

NRPNs provide a great deal of freedom, and can be used with any manufacturer's devices. As a result, any particular parameter number can easily mean one thing when used for a certain device, and mean something completely different on another device. Note that RPNs and NRPNs require that a multiple number of messages be processed in the correct order. However, a majority of the sequencers currently on the market cannot always be relied on to consistently send messages in the proper order if the messages are located at almost exactly the same point in time.

On the GS instruments, NRPN can be used to modify the following parameters. The range of values for relative change parameters will be different with certain models. Please see the explanation that follows the chart.

NRPN	Data entry	Function and range
MSB LSB	MSB	
01H 08H	mmH	Vibrato Rate (relative change) mm: 00H - 40H - 7FH (-64 - 0 - +63)
01H 09H	mmH	Vibrato Depth (relative change) mm: 00H - 40H - 7FH (-64 - 0 - +63)
01H 0AH	mmH	Vibrato Delay (relative change) mm: 00H - 40H - 7FH (-64 - 0 - +63)
01H 20H	mmH	TVF Cutoff Frequency (relative change) mm: 00H - 40H - 7FH (-64 - 0 - +63)
01H 21H	mmH	TVF Resonance (relative change) mm: 00H - 40H - 7FH (-64 - 0 - +63)
01H 63H	mmH	TVF&TVA Envelope Attack Time (relative change) mm: 00H - 40H - 7FH (-64 - 0 - +63)
01H 64H	mmH	TVF&TVA Envelope Decay Time (relative change) mm: 00H - 40H - 7FH (-64 - 0 - +63)
01H 66H	mmH	TVF&TVA Envelope Release Time (relative change) mm: 00H - 40H - 7FH (-64 - 0 - +63)
18H rrH	mmH	Drum Instrument Pitch Coarse (relative change) rr: Drum Instrument note number mm: 00H - 40H - 7FH (-64 - 0 - +63 semitone)
1AH rrH	mmH	Drum Instrument TVA Level (absolute change) rr: Drum Instrument note number mm: 00H - 7FH (0 - max)
1CH rrH	mmH	Drum Instrument Panpot (absolute change) rr: Drum Instrument note number mm: 00H, 01H - 40H - 7FH (random, left - center - right)
1DH rrH	mmH	Drum Instrument Reverb Send Level (absolute change) rr: Drum Instrument note number mm: 00H - 7FH (0 - max)
1EH rrH	mmH	Drum Instrument Chorus Send Level (absolute change) rr: Drum Instrument note number mm: 00H - 7FH (0 - max)

\* Parameters marked "relative change" will change relatively to the preset value(40H). Even among different GS devices, "relative change" parameters may sometimes differ in the way the sound changes or in the range of change.

\* Parameters marked "absolute change" will be set to the absolute value of the parameter, regardless of the preset value.

\* Data entry LSB (llH) is ignored.

## ○RPN MSB/LSB (Controller number 101, 100)

Status	2nd byte	3rd byte
BnH	65H	mmH
BnH	64H	llH

n = MIDI channel number: 0H - FH (ch.1 - 16)  
 mm = upper byte (MSB) of parameter number specified by RPN  
 ll = lower byte (LSB) of parameter number specified by RPN

### \*\*RPN\*\*

The RPN (Registered Parameter Number) messages allows an extended range of control changes to be used, letting you use additional control functions which are part of the MIDI Specification.

RPN	Data entry	Function and range
MSB LSB	MSB LSB	
00H 00H	mmH llH	Pitch Bend Sensitivity mm: 00H - 18H (0 - 24 semitones), Initial value = 02H (2 semitones) ll: ignored (processed as 00H) specify up to 2 octaves in semitone steps.
00H 01H	mmH llH	Channel Fine Tuning mm, ll: 00 00H - 40 00H - 7F 7FH (-100 - 0 - +99.99 cents), Initial value = 40 00H (+/- 0 cent) Refer to "5. Supplementary material", About the Tuning (p. 19).
00H 02H	mmH llH	Channel Coarse Tuning mm: 28H - 40H - 58H (-24 - 0 - +24 semitones), Initial value = 40H (+/- 0 semitone) ll: ignored (processed as 00H)
MSB LSB	MSB LSB	Function and range
00H 05H	mmH llH	Modulation Depth Range mm: 00H - 04H (0 - 4 semitones) ll: 00H - 7FH (0 - 100 cents), 100/128 Cent/Value
7FH 7FH	---	RPN null Set condition where RPN and NRPN are unspecified. The data entry messages after set RPN null will be ignored. (No Data entry messages are required after RPN null). Settings already made will not change. mm, ll: ignored

## ●Program Change

Status	2nd byte
CnH	ppH

n = MIDI channel number: 0H - FH (ch.1 - 16)  
 pp = Program number: 00H - 7FH (prog.1 - prog.128)

\* Not transmitted when Function: Prog Change = OFF. (Initial value is ON)

## ●Pitch Bend Change

Status	2nd byte	3rd byte
EnH	llH	mmH

n = MIDI channel number: 0H - FH (ch.1 - 16)  
 mm, ll = Pitch Bend value: 00 00H - 40 00H - 7F 7FH (-8192 - 0 - +8191)

\* Not transmitted when Function: Pitch Bend = OFF. (Initial value is ON)

## ■System Realtime Messages

### ●Timing Clock

Status
F8H

\* Not transmitted when Function: Clock Tx = OFF. (Initial value is ON)

### ●Song/Style Start

Status
FAH

\* Not transmitted when Function: Start Stop = OFF. (Initial value is ON)

\* This message is transmitted when the internal song/style player is started.



## ● Song Continue

### Status

FBH

- \* Not transmitted when Function: Start Stop = OFF. (Initial value is ON)
- \* This message is transmitted when the internal song player is started not from the beginning.
- \* Transmitted only in Song Mode.

## ● Song/Style Stop

### Status

FCH

- \* Not transmitted when Function: Start Stop = OFF. (Initial value is ON)
- \* This message is transmitted when the internal song/style player is stopped.

## ● Active Sensing

### Status

FEH

- \* This message is transmitted constantly at intervals of approximately 250 msec.

## ■ System Common Message

### ● Song Position Pointer

<u>Status</u>	<u>2nd byte</u>	<u>3rd byte</u>
F2H	llH	hhH

ll = song position LSB: 00H - 7FH  
 hh = song position MSB: 00H - 7FH

- \* Transmitted only in Song Mode.

## ■ System Exclusive Messages

### ● System Exclusive messages related to mode settings

These messages are used to initialize a device to GS or General MIDI mode, or change the operating mode. When creating performance data, a "GM1 System On" message should be inserted at the beginning of a General MIDI 1 score, a "GM2 System On" message at the beginning of a General MIDI 2 score, and a "GS Reset" message at the beginning of a GS music data. Each song should contain only one mode message as appropriate for the type of data. (Do not insert two or more mode setting messages in a single song.) "GM System On" uses Universal Non-realtime Message format. "GS Reset" uses Roland System Exclusive format "Data Set 1 (DT1)".

#### ○ GM1 System On

<u>Status</u>	<u>Data byte</u>	<u>Status</u>
F0H	7EH, 7FH, 09H, 01H	F7H

<u>Byte</u>	<u>Explanation</u>
F0H	Exclusive status
7EH	ID number (Universal Non-realtime Message)
7FH	Device ID (Broadcast)
09H	Sub ID#1 (General MIDI Message)
01H	Sub ID#2 (General MIDI 1 On)
F7H	EOX (End Of Exclusive)

#### ○ GM2 System On

<u>Status</u>	<u>Data byte</u>	<u>Status</u>
F0H	7EH, 7FH, 09H, 03H	F7H

<u>Byte</u>	<u>Explanation</u>
F0H	Exclusive status
7EH	ID number (Universal Non-realtime Message)
7FH	Device ID (Broadcast)
09H	Sub ID#1 (General MIDI Message)
03H	Sub ID#2 (General MIDI 2 On)
F7H	EOX (End Of Exclusive)

#### ○ GM System Off

<u>Status</u>	<u>Data byte</u>	<u>Status</u>
F0H	7EH, 7FH, 09H, 02H	F7H

<u>Byte</u>	<u>Explanation</u>
F0H	Exclusive status
7EH	ID number (Universal Non-realtime Message)
7FH	Device ID (Broadcast)
09H	Sub ID#1 (General MIDI Message)
02H	Sub ID#2 (General MIDI Off)
F7H	EOX (End Of Exclusive)

#### ○ GS Reset

<u>Status</u>	<u>Data byte</u>	<u>Status</u>
F0H	41H, dev, 42H, 12H, 40H, 00H, 7FH, 00H, 41H	F7H

<u>Byte</u>	<u>Explanation</u>
F0H	Exclusive status
41H	ID number (Roland)
dev	Device ID (dev: 00H - 1FH (1 - 32), Initial value is 10H (17))
42H	Model ID (GS)
12H	Command ID (DT1)
40H	Address MSB
00H	Address
7FH	Address LSB
00H	Data (GS reset)
41H	Checksum
F7H	EOX (End Of Exclusive)

# Roland E-09 MIDI Implementation

## ● Universal Non-realtime System Exclusive Message

### ○ Identity Reply Message

Receiving Identity Request Message, the E-09 send this message.

Status	Data byte	Status
F0H	7EH, dev, 06H, 02H, 41H, 17H, 02H, 00H, 00H, 00H, 07H, 00H, 00H	F7H

Byte	Explanation
F0H	Exclusive status
7EH	ID number (Universal Non-realtime Message)
dev	Device ID (dev: 10H - 1FH)
06H	Sub ID#1 (General Information)
02H	Sub ID#2 (Identity Reply)
41H	ID number (Roland)
17H 02H	Device family code
00H 00H	Device family number code
00H 07H 00H 00H	Software revision level
F7H	EOX (End of Exclusive)

## 3. Individual Parameter Transmission

Individual Parameter Transmission transmits data (or requests data) for one parameter as one exclusive message (one packet of "F0 .... F7").

In Individual Parameter Transmission, you must use the Address and Size listed in the following "Parameter Address Map". Addresses marked at "#" cannot be used as starting addresses.

### ■ System Exclusive Messages

When an appropriate "Data Request 1 (RQ1)" message is received, the requested internal data will be transmitted as "Data Set 1 (DT1)".

#### ● Data Request 1 (RQ1)

Status	Data byte	Status
F0H	41H, dev, 42H, 11H, aaH, bbH, ccH, ssH, ttH, uuH, sum	F7H

Byte	Explanation
F0H	Exclusive status
41H	ID number (Roland)
dev	Device ID (dev: 00H - 1FH, Initial value is 10H)
42H	Model ID (GS)
11H	Command ID (RQ1)
aaH	Address MSB: upper byte of the starting address of the requested data.
bbH	Address: middle byte of the starting address of the requested data.
ccH	Address LSB: lower byte of the starting address of the requested data.
ssH	Size MSB
ttH	Size
uuH	Size LSB
sum	Checksum
F7H	EOX (End Of Exclusive)

\* The amount of data that can be transmitted at one time will depend on the type of data, and data must be requested using a specific starting address and size.

\* Regarding the checksum, refer to "5. Supplementary material", Example of an Exclusive message and calculating a checksum (p. 19).

#### ● Data Set 1 (DT1)

Status	Data byte	Status
F0H	41H, dev, 42H, 12H, aaH, bbH, ccH, ddH, ..., sum	F7H

Byte	Explanation
F0H	Exclusive status
41H	ID number (Roland)
dev	Device ID (dev: 00H - 1FH, Initial value is 10H)
42H	Model ID (GS)
12H	Command ID (DT1)
aaH	Address MSB: upper byte of the starting address of the data to be sent.
bbH	Address: middle byte of the starting address of the data to be sent.
ccH	Address LSB: lower byte of the starting address of the data to be sent.
ddH	Data: the actual data to be sent. Multiple bytes of data are transmitted in order starting from the address.
:	:
sum	Checksum
F7H	EOX (End Of Exclusive)

\* The amount of data that can be transmitted at one time depends on the type of data, and data will be transmitted from the specified starting address and size.

\* Data larger than 128 bytes will be divided into packets of 128 bytes or less, and each packet will be sent at an interval of about 40 msec.

\* Regarding the checksum, refer to "5. Supplementary material", Example of an Exclusive message and calculating a checksum (p. 19).

## ■Parameter Address Map

### ●Common parameters (Model ID=42H)

The parameters common to all Parts in each module are called Common parameters.

Address (H)	Size (H)	Data (H)	Parameter	Description	Default Value (H)	Description
40 00 00	00 00 04	0018 - 07E8	MASTER TUNE	-100.0 - +100.0 [cents]	00 04 00 00	0 [cents]
40 00 01#				Use nibblized data.		
40 00 02#						
40 00 03#						

\* Refer to "5. Supplementary material", About the Tuning (p. 19).

Address (H)	Size (H)	Data (H)	Parameter	Description	Default Value (H)	Description
40 00 04	00 00 01	00 - 7F	MASTER VOLUME	0 - 127 (= F0 7F 7F 04 01 00 vv F7)	7F	127
40 00 05	00 00 01	28 - 58	MASTER KEY-SHIFT	-24 - +24 [semitones]	40	0 [semitones]
40 00 06	00 00 01	01 - 7F	MASTER PAN	-63(LEFT)- +63(RIGHT)	40	0(CENTER)
40 00 7F	00 00 01	00	MODE SET	00 = GS Reset (Rx. only)		
40 01 30	00 00 01	00 - 07	REVERB MACRO	00: Room 1 01: Room 2 02: Room 3 03: Hall 1 04: Hall 2 05: Plate 06: Delay 07: Panning Delay	04	Hall 2
40 01 31	00 00 01	00 - 07	REVERB CHARACTER	0 - 7	04	4
40 01 32	00 00 01	00 - 07	REVERB PRE-LPF	0 - 7	00	0
40 01 33	00 00 01	00 - 7F	REVERB LEVEL	0 - 127	40	64
40 01 34	00 00 01	00 - 7F	REVERB TIME	0 - 127	40	64
40 01 35	00 00 01	00 - 7F	REVERB DELAY FEEDBACK	0 - 127	00	0
40 01 37	00 00 01	00 - 7F	REVERB PREDELAY TIME	0 - 127[ms]	00	0

\* REVERB MACRO is a macro parameter that allows global setting of reverb parameters. When you select the reverb type with REVERB MACRO, each reverb parameter will be set to their most suitable value.

\* REVERB CHARACTER is a parameter that changes the reverb algorithm. The value of REVERB CHARACTER corresponds to the REVERB MACRO of the same number.

Address (H)	Size (H)	Data (H)	Parameter	Description	Default Value (H)	Description
40 01 38	00 00 01	00 - 07	CHORUS MACRO	00: Chorus 1 01: Chorus 2 02: Chorus 3 03: Chorus 4 04: Feedback Chorus 05: Flanger 06: Short Delay 07: Short Delay(FB)	02	Chorus 3
40 01 39	00 00 01	00 - 07	CHORUS PRE-LPF	0-7	00	0
40 01 3A	00 00 01	00 - 7F	CHORUS LEVEL	0-127	40	64
40 01 3B	00 00 01	00 - 7F	CHORUS FEEDBACK	0-127	08	8
40 01 3C	00 00 01	00 - 7F	CHORUS DELAY	0-127	50	80
40 01 3D	00 00 01	00 - 7F	CHORUS RATE	0-127	03	3
40 01 3E	00 00 01	00 - 7F	CHORUS DEPTH	0-127	13	19
40 01 3F	00 00 01	00 - 7F	CHORUS SEND LEVEL TO REVERB	0-127	00	0

\* CHORUS MACRO is a macro parameter that allows global setting of chorus parameters. When you select the chorus type with CHORUS MACRO, each Chorus parameter will be set to their most suitable value.

Address (H)	Size (H)	Data (H)	Parameter	Description	Default Value (H)	Description
40 03 17	00 00 01	00 - 7F	MFx SEND LEVEL TO REVERB	0-127	28	40

\* MFx TYPE is a macro parameter which sets various Insertion Effect parameters as a group. When you use MFx TYPE to select an Insertion Effect type, each effect parameter will be set to the most suitable value.

# Roland E-09 MIDI Implementation

## ●MFX Effect List

00:Off			
Effect Type	F0 41 10 42 12 40 03 00 00 3D F7	Thru	
01:Enhancer			
Effect Type	F0 41 10 42 12 40 03 00 01 02 3A F7	Enhancer	
Sens = 127	F0 41 10 42 12 40 03 03 7F 3B F7	Value Hex. 00-7F	
Mix = 64	F0 41 10 42 12 40 03 04 40 79 F7	Value Hex. 00-7F	
02:Overdrive 1			
Effect Type	F0 41 10 42 12 40 03 00 01 10 2C F7	Overdrive	
Amp Type Small	F0 41 10 42 12 40 03 04 00 39 F7	Small	
Drive = 48	F0 41 10 42 12 40 03 03 30 0A F7	Value Hex. 00-7F	
Pan = 64	F0 41 10 42 12 40 03 15 40 68 F7	Value Hex. 00-7F	
03:Overdrive 2			
Effect Type	F0 41 10 42 12 40 03 00 01 10 2C F7	Overdrive	
Amp Type BltIn	F0 41 10 42 12 40 03 04 01 38 F7	BltIn (Default)	
Drive = 48	F0 41 10 42 12 40 03 03 30 0A F7	Value Hex. 00-7F	
Pan = 64	F0 41 10 42 12 40 03 15 40 68 F7	Value Hex. 00-7F	
04:Overdrive 3			
Effect Type	F0 41 10 42 12 40 03 00 01 10 2C F7	Overdrive	
Amp Type 2-Stk	F0 41 10 42 12 40 03 04 02 37 F7	2-Stk	
Drive = 48	F0 41 10 42 12 40 03 03 30 0A F7	Value Hex. 00-7F	
Pan = 64	F0 41 10 42 12 40 03 15 40 68 F7	Value Hex. 00-7F	
05:Overdrive 4			
Effect Type	F0 41 10 42 12 40 03 00 01 10 2C F7	Overdrive	
Amp Type 3-Stk	F0 41 10 42 12 40 03 04 03 36 F7	3-Stk	
Drive = 48	F0 41 10 42 12 40 03 03 30 0A F7	Value Hex. 00-7F	
Pan = 64	F0 41 10 42 12 40 03 15 40 68 F7	Value Hex. 00-7F	
06:Distortion 1			
Effect Type	F0 41 10 42 12 40 03 00 01 11 2B F7	Distortion	
Amp Type Small	F0 41 10 42 12 40 03 04 00 39 F7	Small	
Drive = 76	F0 41 10 42 12 40 03 03 4C 6E F7	Value Hex. 00-7F	
Pan = 64	F0 41 10 42 12 40 03 15 40 68 F7	Value Hex. 00-7F	
07:Distortion 2			
Effect Type	F0 41 10 42 12 40 03 00 01 11 2B F7	Distortion	
Amp Type BltIn	F0 41 10 42 12 40 03 04 01 38 F7	BltIn	
Drive = 76	F0 41 10 42 12 40 03 03 4C 6E F7	Value Hex. 00-7F	
Pan = 64	F0 41 10 42 12 40 03 15 40 68 F7	Value Hex. 00-7F	
08:Distortion 3			
Effect Type	F0 41 10 42 12 40 03 00 01 11 2B F7	Distortion	
Amp Type 2-Stk	F0 41 10 42 12 40 03 04 02 37 F7	2-Stk	
Drive = 76	F0 41 10 42 12 40 03 03 4C 6E F7	Value Hex. 00-7F	
Pan = 64	F0 41 10 42 12 40 03 15 40 68 F7	Value Hex. 00-7F	
09:Distortion 4			
Effect Type	F0 41 10 42 12 40 03 00 01 11 2B F7	Distortion	
Amp Type 3-Stk	F0 41 10 42 12 40 03 04 03 36 F7	3-Stk (Default)	
Drive = 76	F0 41 10 42 12 40 03 03 4C 6E F7	Value Hex. 00-7F	
Pan = 64	F0 41 10 42 12 40 03 15 40 68 F7	Value Hex. 00-7F	
10:Phaser			
Effect Type	F0 41 10 42 12 40 03 00 01 20 1C F7	Phaser	
Manual = 36	F0 41 10 42 12 40 03 03 24 16 F7	ValueHex.00-24-F7	
Rate = 16	F0 41 10 42 12 40 03 04 10 29 F7	Value Hex. 00-7F	
11:Auto Wah			
Effect Type	F0 41 10 42 12 40 03 00 01 21 1B F7	Auto Wah	
Manual = 68	F0 41 10 42 12 40 03 05 44 74 F7	Value Hex. 00-7F	
Rate = 40	F0 41 10 42 12 40 03 07 28 0E F7	Value Hex. 00-7F	
12:Rotary (Slow)			
Effect Type	F0 41 10 42 12 40 03 00 01 22 1A F7	Rotary (Slow)	
Speed = 0	F0 41 10 42 12 40 03 0D 00 30 F7	Value Hex. 00-7F	
Level = 127	F0 41 10 42 12 40 03 16 7F 28 F7	Value Hex. 00-7F	
12:Rotary (Fast)			
Effect Type	F0 41 10 42 12 40 03 00 01 22 1A F7	Rotary (Fast)	
Speed = 127	F0 41 10 42 12 40 03 0D 7F 31 F7	Value Hex. 00-7F	
Level = 127	F0 41 10 42 12 40 03 16 7F 28 F7	Value Hex. 00-7F	
13:St Flanger			
Effect Type	F0 41 10 42 12 40 03 00 01 23 19 F7	Stereo Flanger	
Rate = 11	F0 41 10 42 12 40 03 06 0B 2C F7	Value Hex. 00-7F	
Feedback = 104	F0 41 10 42 12 40 03 08 68 4D F7	Value Hex. 0F-71	
14:Step Flanger			
Effect Type	F0 41 10 42 12 40 03 00 01 24 18 F7	Step Flanger	
Feedback = 39	F0 41 10 42 12 40 03 06 27 10 F7	Value Hex. 0F-71	
Step Rate = 54	F0 41 10 42 12 40 03 08 36 7F F7	Value Hex. 00-7F	
15:Compressor			
Effect Type	F0 41 10 42 12 40 03 00 01 30 0C F7	Compressor	
Pan = 64	F0 41 10 42 12 40 03 15 40 68 F7	Value Hex. 00-7F	
Level = 104	F0 41 10 42 12 40 03 16 68 3F F7	Value Hex. 00-7F	
16:Limiter			
Effect Type	F0 41 10 42 12 40 03 00 01 31 0B F7	Limiter	
Pan = 64	F0 41 10 42 12 40 03 15 40 68 F7	Value Hex. 00-7F	
Level = 127	F0 41 10 42 12 40 03 16 7F 28 F7	Value Hex. 00-7F	
17:Hexa Chorus			
Effect Type	F0 41 10 42 12 40 03 00 01 40 7C F7	Hexa Chorus	
Rate = 32	F0 41 10 42 12 40 03 04 20 19 F7	Value Hex. 00-7F	
Balance = 64	F0 41 10 42 12 40 03 12 40 6B F7	Value Hex. 00-7F	
18:Trem Chorus			
Effect Type	F0 41 10 42 12 40 03 00 01 41 7B F7	Tremolo Chorus	
Trem Rate = 60	F0 41 10 42 12 40 03 07 3C 7A F7	Value Hex. 00-7F	
Balance = 55	F0 41 10 42 12 40 03 12 37 74 F7	Value Hex. 00-7F	
19:St Chorus			
Effect Type	F0 41 10 42 12 40 03 00 01 42 7A F7	Stereo Chorus	
Rate = 16	F0 41 10 42 12 40 03 06 10 27 F7	Value Hex. 00-7F	
Balance = 40	F0 41 10 42 12 40 03 12 28 03 F7	Value Hex. 00-7F	
20:Space-D			
Effect Type	F0 41 10 42 12 40 03 00 01 43 79 F7	Space D	
Rate = 16	F0 41 10 42 12 40 03 04 10 29 F7	Value Hex. 00-7F	
Balance = 64	F0 41 10 42 12 40 03 12 40 6B F7	Value Hex. 00-7F	
21:St Delay			
Effect Type	F0 41 10 42 12 40 03 00 01 50 6C F7	Stereo Delay	
Feedback = 80	F0 41 10 42 12 40 03 05 50 68 F7	Value Hex. 0F-71	
Balance = 40	F0 41 10 42 12 40 03 12 28 03 F7	Value Hex. 00-7F	
22:Mod Delay			
Effect Type	F0 41 10 42 12 40 03 00 01 51 6B F7	Mod Delay	
Mod Rate = 12	F0 41 10 42 12 40 03 07 0C 2A F7	Value Hex. 00-7F	
Balance = 40	F0 41 10 42 12 40 03 12 28 03 F7	Value Hex. 00-7F	
23:3 Tap Delay			
Effect Type	F0 41 10 42 12 40 03 00 01 52 6A F7	3 Tap Delay	
Feedback = 80	F0 41 10 42 12 40 03 06 29 0E F7	Value Hex. 0F-71	
Balance = 48	F0 41 10 42 12 40 03 12 30 7B F7	Value Hex. 00-7F	
24:4 Tap Delay			
Effect Type	F0 41 10 42 12 40 03 00 01 53 69 F7	4 Tap Delay	
Feedback = 41	F0 41 10 42 12 40 03 0B 29 09 F7	Value Hex. 0F-71	
Balance = 48	F0 41 10 42 12 40 03 12 30 7B F7	Value Hex. 00-7F	
25:Tm Ctrl Dly			
Effect Type	F0 41 10 42 12 40 03 00 01 54 68 F7	Time Control Delay	
Dly Time = 60	F0 41 10 42 12 40 03 03 3C 7E F7	Value Hex. 00-7F	
Feedback = 41	F0 41 10 42 12 40 03 05 29 0F F7	Value Hex. 00-7F	
26:Reverb			
Effect Type	F0 41 10 42 12 40 03 00 01 55 67 F7	Reverb	
Time = 100	F0 41 10 42 12 40 03 05 64 54 F7	Value Hex. 00-7F	
Balance = 50	F0 41 10 42 12 40 03 12 32 79 F7	Value Hex. 00-7F	
27:Gate Rev Nr			
Effect Type	F0 41 10 42 12 40 03 00 01 56 66 F7	Gate Reverb	
Type Norm	F0 41 10 42 12 40 03 03 00 3A F7	Norm (Default)	
Balance = 33	F0 41 10 42 12 40 03 12 21 0A F7	Value Hex. 00-7F	
Level = 120	F0 41 10 42 12 40 03 16 78 2F F7	Value Hex. 00-7F	

# Roland E-09 MIDI Implementation

28:Gate Rev Rv		
Effect Type	F0 41 10 42 12 40 03 00 01 56 66 F7	Gate Reverb
Type Reverse	F0 41 10 42 12 40 03 03 01 39 F7	Reverse
Balance = 42	F0 41 10 42 12 40 03 12 2A 01 F7	Value Hex. 00-7F
Level = 112	F0 41 10 42 12 40 03 16 70 37 F7	Value Hex. 00-7F
29:Gate Rev S1		
Effect Type	F0 41 10 42 12 40 03 00 01 56 66 F7	Gate Reverb
Type Sweep1	F0 41 10 42 12 40 03 03 02 38 F7	Sweep1
Balance = 35	F0 41 10 42 12 40 03 12 23 08 F7	Value Hex. 00-7F
Level = 120	F0 41 10 42 12 40 03 16 78 2F F7	Value Hex. 00-7F
30:Gate Rev S2		
Effect Type	F0 41 10 42 12 40 03 00 01 56 66 F7	Gate Reverb
Type Sweep2	F0 41 10 42 12 40 03 03 03 37 F7	Sweep2
Balance = 42	F0 41 10 42 12 40 03 12 2A 01 F7	Value Hex. 00-7F
Level = 112	F0 41 10 42 12 40 03 16 70 37 F7	Value Hex. 00-7F
31:2 Pitch Shift		
Effect Type	F0 41 10 42 12 40 03 00 01 60 5C F7	2 Pitch Shifter
Coarse1 = 71	F0 41 10 42 12 40 03 03 47 73 F7	Value Hex. 28-4C
Coarse2 = 59	F0 41 10 42 12 40 03 07 3B 7B F7	Value Hex. 28-4C
32:Fb Pitch Shift		
Effect Type	F0 41 10 42 12 40 03 00 01 61 5B F7	Fb Pitch Shifter
P.Coarse = 71	F0 41 10 42 12 40 03 03 47 73 F7	Value Hex. 28-4C
Feedback = 76	F0 41 10 42 12 40 03 05 4C 6C F7	Value Hex. 0F-7F
33:OD>Chorus		
Effect Type	F0 41 10 42 12 40 03 00 02 00 3B F7	OD > Chorus
OD Pan = 64	F0 41 10 42 12 40 03 04 40 79 F7	Value Hex. 00-7F
Cho Bal = 64	F0 41 10 42 12 40 03 0C 40 71 F7	Value Hex. 00-7F
34:OD>Flanger		
Effect Type	F0 41 10 42 12 40 03 00 02 01 3A F7	OD > Flanger
OD Pan = 64	F0 41 10 42 12 40 03 04 40 79 F7	Value Hex. 00-7F
FL Bal = 32	F0 41 10 42 12 40 03 0C 20 11 F7	Value Hex. 00-7F
35:OD>Delay		
Effect Type	F0 41 10 42 12 40 03 00 02 02 39 F7	OD > Delay
OD Pan = 64	F0 41 10 42 12 40 03 04 40 79 F7	Value Hex. 00-7F
Dly Bal = 48	F0 41 10 42 12 40 03 0C 30 01 F7	Value Hex. 00-7F
36:DS>Chorus		
Effect Type	F0 41 10 42 12 40 03 00 02 03 38 F7	DS > Chorus
DS Pan = 64	F0 41 10 42 12 40 03 04 40 79 F7	Value Hex. 00-7F
Cho Bal = 64	F0 41 10 42 12 40 03 0C 40 71 F7	Value Hex. 00-7F
37:DS>Flanger		
Effect Type	F0 41 10 42 12 40 03 00 02 04 37 F7	DS > Flanger
DS Pan = 64	F0 41 10 42 12 40 03 04 40 79 F7	Value Hex. 00-7F
FL Bal = 32	F0 41 10 42 12 40 03 0C 20 11 F7	Value Hex. 00-7F
38:DS>Delay		
Effect Type	F0 41 10 42 12 40 03 00 02 05 36 F7	DS > Delay
DS Pan = 64	F0 41 10 42 12 40 03 04 40 79 F7	Value Hex. 00-7F
Dly Bal = 48	F0 41 10 42 12 40 03 0C 30 01 F7	Value Hex. 00-7F
39:EH>Chorus		
Effect Type	F0 41 10 42 12 40 03 00 02 06 35 F7	EH > Chorus
EH Sens = 64	F0 41 10 42 12 40 03 03 40 7A F7	Value Hex. 00-7F
Cho Bal = 64	F0 41 10 42 12 40 03 0C 40 71 F7	Value Hex. 00-7F
40:EH>Flanger		
Effect Type	F0 41 10 42 12 40 03 00 02 07 34 F7	EH > Flanger
EH Sens = 64	F0 41 10 42 12 40 03 03 40 7A F7	Value Hex. 00-7F
FL Bal = 48	F0 41 10 42 12 40 03 0C 30 01 F7	Value Hex. 00-7F
41:EH>Delay		
Effect Type	F0 41 10 42 12 40 03 00 02 08 33 F7	EH > Delay
EH Sens = 64	F0 41 10 42 12 40 03 03 40 7A F7	Value Hex. 00-7F
Dly Bal = 48	F0 41 10 42 12 40 03 0C 30 01 F7	Value Hex. 00-7F
42:Cho>Delay		
Effect Type	F0 41 10 42 12 40 03 00 02 09 32 F7	Cho > Delay
Cho Bal = 64	F0 41 10 42 12 40 03 07 40 76 F7	Value Hex. 00-7F
Dly Bal = 48	F0 41 10 42 12 40 03 0C 30 01 F7	Value Hex. 00-7F

43:FL>Delay		
Effect Type	F0 41 10 42 12 40 03 00 02 0A 31 F7	FL > Delay
FL Fb = 104	F0 41 10 42 12 40 03 06 68 4F F7	Value Hex. 0F-7F
Dly Bal = 48	F0 41 10 42 12 40 03 0C 30 01 F7	Value Hex. 00-7F
44:Cho>Flanger		
Effect Type	F0 41 10 42 12 40 03 00 02 0B 30 F7	Cho > Flanger
Cho Bal = 64	F0 41 10 42 12 40 03 07 40 76 F7	Value Hex. 00-7F
FL Bal = 64	F0 41 10 42 12 40 03 0C 40 71 F7	Value Hex. 00-7F
45:Cho/Delay		
Effect Type	F0 41 10 42 12 40 03 00 11 00 2C F7	Cho / Delay
Cho Bal = 64	F0 41 10 42 12 40 03 07 40 76 F7	Value Hex. 00-7F
Dly Bal = 40	F0 41 10 42 12 40 03 0C 28 09 F7	Value Hex. 00-7F
46:FL/Delay		
Effect Type	F0 41 10 42 12 40 03 00 11 01 2B F7	FL / Delay
FL Bal = 64	F0 41 10 42 12 40 03 07 40 76 F7	Value Hex. 00-7F
Dly Bal = 48	F0 41 10 42 12 40 03 0C 30 01 F7	Value Hex. 00-7F
47:Cho/Flanger		
Effect Type	F0 41 10 42 12 40 03 00 11 02 2A F7	Cho / Flanger
Cho Bal = 64	F0 41 10 42 12 40 03 07 40 76 F7	Value Hex. 00-7F
FL Bal = 64	F0 41 10 42 12 40 03 0C 40 71 F7	Value Hex. 00-7F

## ●Effect Type only from MIDI

Equalizer		
Effect Type	F0 41 10 42 12 40 03 00 01 00 3C F7	Stereo EQ
Spectrum		
Effect Type	F0 41 10 42 12 40 03 00 01 01 3B F7	Spectrum

## ●Part parameters (Model ID=42H)

The E-09 has 32 Parts: 16 Parts for Arranger and Keyboard Parts, and 16 Parts for Songs.  
If you like to send messages to the 16 Parts relative to Arranger and Keyboard, you have to use the address 50 nn nn.  
If you like to send messages to the 16 Parts relative to Songs, you have to use the address 40 nn nn.

The 32 Parts are:

Arranger and Keyboard Parts			
Track	Name	MIDI Channel	SysEx (x=)
1	Accomp 1	Ch 1	x=1
2	Accomp Bass	Ch 2	x=2
3	Accomp 2	Ch 3	x=3
4	Main	Ch 4	x=4
5	Accomp 3	Ch 5	x=5
6	Dual	Ch 6	x=6
7	Accomp 4	Ch 7	x=7
8	Accomp 5	Ch 8	x=8
9	Accomp 6	Ch 9	x=9
10	Accomp Drums	Ch 10	x=0
11	Split	Ch 11	x=A
12	Auto Bass	Ch 12	x=B
13	---	Ch 13	x=C
14	---	Ch 14	x=D
15	Melody Int	Ch 15	x=E
16	Main Drums	Ch 16	x=F

Song Parts

Track	Name	MIDI Channel	SysEx (x=)
1	Part 1	Ch 1	x=1
2	Part 2	Ch 2	x=2
3	Part 3	Ch 3	x=3
4	Part 4	Ch 4	x=4
5	Part 5	Ch 5	x=5
6	Part 6	Ch 6	x=6
7	Part 7	Ch 7	x=7
8	Part 8	Ch 8	x=8
9	Part 9	Ch 9	x=9
10	Part 10	Ch 10	x=0
11	Part 11	Ch 11	x=A
12	Part 12	Ch 12	x=B
13	Part 13	Ch 13	x=C
14	Part 14	Ch 14	x=D
15	Part 15	Ch 15	x=E
16	Part 16	Ch 16	x=F

# Roland E-09 MIDI Implementation

In the following map, the control numbers of the control changes are indicated as CC#.

Address (H)	Size (H)	Data (H)	Parameter	Description	Default Value (H)	Description
40 1x 00	00 00 02	00 - 7F	TONE NUMBER	CC# 00 VALUE 0 - 127	00	0
40 1x 01#		00 - 7F		P.C. VALUE 1 - 128	00	1
40 1x 02	00 00 01	00 - 10	Rx. CHANNEL	1 - 16, OFF	Same as the Part Number	
40 1x 03	00 00 01	00, 01	Rx. PITCH BEND	OFF/ON	01	ON
40 1x 04	00 00 01	00, 01	Rx. CH PRESSURE(CAf)	OFF/ON	01	ON
40 1x 05	00 00 01	00, 01	Rx. PROGRAM CHANGE	OFF/ON	01	ON
40 1x 06	00 00 01	00, 01	Rx. CONTROL CHANGE	OFF/ON	01	ON
40 1x 07	00 00 01	00, 01	Rx. POLY PRESSURE(PAf)	OFF/ON	01	ON
40 1x 08	00 00 01	00, 01	Rx. NOTE MESSAGE	OFF/ON	01	ON
40 1x 09	00 00 01	00, 01	Rx. RPN	OFF/ON	01	ON
40 1x 0A	00 00 01	00, 01	Rx. NRPN	OFF/ON	00(01*)	OFF(ON*)

\* When "GM1 System On" or "GM2 System On" is received, Rx. NRPN will be set OFF. When "GS Reset" is received, it will be set ON.

Address (H)	Size (H)	Data (H)	Parameter	Description	Default Value (H)	Description
40 1x 0B	00 00 01	00, 01	Rx. MODULATION	OFF/ON	01	ON
40 1x 0C	00 00 01	00, 01	Rx. VOLUME	OFF/ON	01	ON
40 1x 0D	00 00 01	00, 01	Rx. PANPOT	OFF/ON	01	ON
40 1x 0E	00 00 01	00, 01	Rx. EXPRESSION	OFF/ON	01	ON
40 1x 0F	00 00 01	00, 01	Rx. HOLD1	OFF/ON	01	ON
40 1x 10	00 00 01	00, 01	Rx. PORTAMENTO	OFF/ON	01	ON
40 1x 11	00 00 01	00, 01	Rx. SOSTENUTO	OFF/ON	01	ON
40 1x 12	00 00 01	00, 01	Rx. SOFT	OFF/ON	01	ON
40 1x 13	00 00 01	00, 01	MONO/POLY MODE	Mono/Poly (=CC# 126 01/CC# 127 00)	01	Poly
40 1x 14	00 00 01	00 - 02	ASSIGN MODE	0 = SINGLE 1 = LIMITED-MULTI 2 = FULL-MULTI	01 00 at x=0 01 at x≠0	LIMITED-MULTI SINGLE(Drum Part) LIMITED-MULTI(Normal Part)

Single: If the same note is played multiple times in succession, the previously-sounding note will be completely silenced, and then the new note will be sounded.

LimitedMulti: If the same note is played multiple times in succession, the previously-sounding note will be continued to a certain extent even after the new note is sounded (default setting).

FullMulti: If the same note is played multiple times in succession, the previously-sounding note(s) will continue sounding for their natural length even after the new note is sounded.

\* ASSIGN MODE is the parameter that determines how voice assignment will be handled when sounds overlap on identical note numbers in the same channel (i.e., repeatedly struck notes). This is initialized to a mode suitable for each Part, so for general purposes there is no need to change this.

Address (H)	Size (H)	Data (H)	Parameter	Description	Default Value (H)	Description
40 1x 15	00 00 01	00 - 02	USE FOR RHYTHM PART	0 = OFF 1 = MAP1 2 = MAP2	00 at x≠0 01 at x=0	OFF(Normal Part) MAP1(Drum Part)

\* This parameter sets the Drum Map of the Part used as the Drum Part. The E-09 can simultaneously (in different Parts) use up to two Drum Maps (MAP1, MAP2). With the initial settings, Part10 (MIDI CH=10, x=0) is set to MAP1 (1), and other Parts are set to normal instrumental Parts (OFF(0)).

Address (H)	Size (H)	Data (H)	Parameter	Description	Default Value (H)	Description
40 1x 16	00 00 01	28 - 58	PITCH KEY SHIFT	-24 - +24 [semitones]	40	0 [semitones]
40 1x 17	00 00 02	08 - F8	PITCH OFFSET FINE	-12.0 - +12.0 [Hz]	08 00	0 [Hz]
40 1x 18#				Use nibblized data.		

\* PITCH OFFSET FINE allows you to alter, by a specified frequency amount, the pitch at which notes will sound. This parameter differs from the conventional Fine Tuning (RPN #1) parameter in that the amount of frequency alteration (in Hertz) will be identical no matter which note is played. When a multiple number of Parts, each of which has been given a different setting for PITCH OFFSET FINE, are sounded by means of an identical note number, you can obtain a Celeste effect.

Address (H)	Size (H)	Data (H)	Parameter	Description	Default Value (H)	Description
40 1x 19	00 00 01	00 - 7F	PART LEVEL	0 - 127 (=CC# 7)	64	100
40 1x 1A	00 00 01	00 - 7F	VELOCITY SENSE DEPTH	0 - 127	40	64
40 1x 1B	00 00 01	00 - 7F	VELOCITY SENSE OFFSET	0 - 127	40	64
40 1x 1C	00 00 01	00 - 7F	PART PANPOT	-64(RANDOM), -63(LEFT)- +63(RIGHT) (=CC# 10, except RANDOM)	40	0(CENTER)
40 1x 1D	00 00 01	00 - 7F	KEYBOARD RANGE LOW	(C-1)-(G9)	00	C-1
40 1x 1E	00 00 01	00 - 7F	KEYBOARD RANGE HIGH	(C-1)-(G9)	7F	G 9
40 1x 1F	00 00 01	00 - 5F	CC1 CONTROLLER NUMBER	0 - 95	10	16
40 1x 20	00 00 01	00 - 5F	CC2 CONTROLLER NUMBER	0 - 95	11	17
40 1x 21	00 00 01	00 - 7F	CHORUS SEND LEVEL	0 - 127 (=CC# 93)	00	0
40 1x 22	00 00 01	00 - 7F	REVERB SEND LEVEL	0 - 127 (=CC# 91)	28	40

# Roland E-09 MIDI Implementation

Address (H)	Size (H)	Data (H)	Parameter	Description	Default Value (H)	Description
40 1x 23	00 00 01	00, 01	Rx.BANK SELECT	OFF/ON	01(00*)	ON(OFF*)

- \* When "GM1 System On" is received, Rx.BANK SELECT will be set to OFF.
- \* When "GM2 System On" or "GS RESET" is received, Rx.BANK SELECT will be set to ON.

Address (H)	Size (H)	Data (H)	Parameter	Description	Default Value (H)	Description
40 1x 24	00 00 01	00, 01	RX BANK SELECT LSB	OFF/ON	01	ON

- \* When RX BANK SELECT LSB = OFF, Bank Select LSB (Bn 20 11) will be treated as 00H regardless of its value.

Address (H)	Size (H)	Data (H)	Parameter	Description	Default Value (H)	Description
40 1x 2A	00 00 02	00 00 - 40 00 - 7F 7F	PITCH FINE TUNE	-100 - 0 - +100 [cents] (= RPN#1)	40 00	0
40 1x 2B#						
40 1x 30	00 00 01	00 - 7F	TONE MODIFY1 Vibrato Rate	-64 - +63 (=NRPN# 8/CC# 76)	40	0
40 1x 31	00 00 01	00 - 7F	TONE MODIFY2 Vibrato Depth	-64 - +63 (=NRPN# 9/CC# 77)	40	0
40 1x 32	00 00 01	00 - 7F	TONE MODIFY3 TVF Cutoff Freq	-64 - +63 (=NRPN# 32/CC# 74)	40	0
40 1x 33	00 00 01	00 - 7F	TONE MODIFY4 TVF Resonance	-64 - +63 (=NRPN# 33/CC# 71)	40	0
40 1x 34	00 00 01	00 - 7F	TONE MODIFY5 TVF&TVA Env.attack	-64 - +63 (=NRPN# 99/CC# 73)	40	0
40 1x 35	00 00 01	00 - 7F	TONE MODIFY6 TVF&TVA Env.decay	-64 - +63 (=NRPN# 100/CC# 75)	40	0
40 1x 36	00 00 01	00 - 7F	TONE MODIFY7 TVF&TVA Env.release	-64 - +63 (=NRPN# 102/CC# 72)	40	0
40 1x 37	00 00 01	00 - 7F	TONE MODIFY8 Vibrato Delay	-64 - +63 (=NRPN# 10/CC# 78)	40	0
40 1x 40	00 00 0C	00 - 7F	SCALE TUNING C	-64 - +63 [cents]	40	0 [cents]
40 1x 41#		00 - 7F	SCALE TUNING C#	-64 - +63 [cents]	40	0 [cents]
40 1x 42#		00 - 7F	SCALE TUNING D	-64 - +63 [cents]	40	0 [cents]
40 1x 43#		00 - 7F	SCALE TUNING D#	-64 - +63 [cents]	40	0 [cents]
40 1x 44#		00 - 7F	SCALE TUNING E	-64 - +63 [cents]	40	0 [cents]
40 1x 45#		00 - 7F	SCALE TUNING F	-64 - +63 [cents]	40	0 [cents]
40 1x 46#		00 - 7F	SCALE TUNING F#	-64 - +63 [cents]	40	0 [cents]
40 1x 47#		00 - 7F	SCALE TUNING G	-64 - +63 [cents]	40	0 [cents]
40 1x 48#		00 - 7F	SCALE TUNING G#	-64 - +63 [cents]	40	0 [cents]
40 1x 49#		00 - 7F	SCALE TUNING A	-64 - +63 [cents]	40	0 [cents]
40 1x 4A#		00 - 7F	SCALE TUNING A#	-64 - +63 [cents]	40	0 [cents]
40 1x 4B#		00 - 7F	SCALE TUNING B	-64 - +63 [cents]	40	0 [cents]

- \* SCALE TUNING is a function that allows fine adjustment to the pitch of each note in the octave. The pitch of each identically-named note in all octaves will change simultaneously. A setting of +/- 0 cents (40H) is equal temperament (p. 19).

Address (H)	Size (H)	Data (H)	Parameter	Description	Default Value (H)	Description
40 2x 00	00 00 01	28 - 58	MOD PITCH CONTROL	-24 - +24 [semitones]	40	0 [semitones]
40 2x 01	00 00 01	00 - 7F	MOD TVF CUTOFF CONTROL	-9600 - +9600 [cents]	40	0 [cents]
40 2x 02	00 00 01	00 - 7F	MOD AMPLITUDE CONTROL	-100.0 - +100.0 [%]	40	0 [%]
40 2x 03	00 00 01	00 - 7F	MOD LFO1 RATE CONTROL	-10.0 - +10.0 [Hz]	40	0 [Hz]
40 2x 04	00 00 01	00 - 7F	MOD LFO1 PITCH DEPTH	0 - 600 [cents]	0A	10 [cents]
40 2x 05	00 00 01	00 - 7F	MOD LFO1 TVF DEPTH	0 - 2400 [cents]	00	0 [cents]
40 2x 06	00 00 01	00 - 7F	MOD LFO1 TVA DEPTH	0 - 100.0 [%]	00	0 [%]
40 2x 07	00 00 01	00 - 7F	MOD LFO2 RATE CONTROL	-10.0 - +10.0 [Hz]	40	0 [Hz]
40 2x 08	00 00 01	00 - 7F	MOD LFO2 PITCH DEPTH	0 - 600 [cents]	00	0 [cents]
40 2x 09	00 00 01	00 - 7F	MOD LFO2 TVF DEPTH	0 - 2400 [cents]	00	0 [cents]
40 2x 0A	00 00 01	00 - 7F	MOD LFO2 TVA DEPTH	0 - 100.0 [%]	00	0 [%]
40 2x 10	00 00 01	40 - 58	BEND PITCH CONTROL	0 - 24 [semitones]	42	2 [semitones]
40 2x 11	00 00 01	00 - 7F	BEND TVF CUTOFF CONTROL	-9600 - +9600 [cents]	40	0 [cents]
40 2x 12	00 00 01	00 - 7F	BEND AMPLITUDE CONTROL	-100.0 - +100.0 [%]	40	0 [%]
40 2x 13	00 00 01	00 - 7F	BEND LFO1 RATE CONTROL	-10.0 - +10.0 [Hz]	40	0 [Hz]
40 2x 14	00 00 01	00 - 7F	BEND LFO1 PITCH DEPTH	0 - 600 [cents]	00	0 [cents]
40 2x 15	00 00 01	00 - 7F	BEND LFO1 TVF DEPTH	0 - 2400 [cents]	00	0 [cents]
40 2x 16	00 00 01	00 - 7F	BEND LFO1 TVA DEPTH	0 - 100.0 [%]	00	0 [%]
40 2x 17	00 00 01	00 - 7F	BEND LFO2 RATE CONTROL	-10.0 - +10.0 [Hz]	40	0 [Hz]
40 2x 18	00 00 01	00 - 7F	BEND LFO2 PITCH DEPTH	0 - 600 [cents]	00	0 [cents]
40 2x 19	00 00 01	00 - 7F	BEND LFO2 TVF DEPTH	0 - 2400 [cents]	00	0 [cents]
40 2x 1A	00 00 01	00 - 7F	BEND LFO2 TVA DEPTH	0 - 100.0 [%]	00	0 [%]
40 2x 20	00 00 01	28 - 58	CAf PITCH CONTROL	-24 - +24 [semitones]	40	0 [semitones]
40 2x 21	00 00 01	00 - 7F	CAf TVF CUTOFF CONTROL	-9600 - +9600 [cents]	40	0 [cents]
40 2x 22	00 00 01	00 - 7F	CAf AMPLITUDE CONTROL	-100.0 - +100.0 [%]	40	0 [%]
40 2x 23	00 00 01	00 - 7F	CAf LFO1 RATE CONTROL	-10.0 - +10.0 [Hz]	40	0 [Hz]
40 2x 24	00 00 01	00 - 7F	CAf LFO1 PITCH DEPTH	0 - 600 [cents]	00	0 [cents]

# Roland E-09 MIDI Implementation

Address (H)	Size (H)	Data (H)	Parameter	Description	Default Value (H)	Description
40 2x 25	00 00 01	00 - 7F	CAf LFO1 TVF DEPTH	0 - 2400 [cents]	00	0 [cents]
40 2x 26	00 00 01	00 - 7F	CAf LFO1 TVA DEPTH	0 - 100.0 [%]	00	0 [%]
40 2x 27	00 00 01	00 - 7F	CAf LFO2 RATE CONTROL	-10.0 - +10.0 [Hz]	40	0 [Hz]
40 2x 28	00 00 01	00 - 7F	CAf LFO2 PITCH DEPTH	0 - 600 [cents]	00	0 [cents]
40 2x 29	00 00 01	00 - 7F	CAf LFO2 TVF DEPTH	0 - 2400 [cents]	00	0 [cents]
40 2x 2A	00 00 01	00 - 7F	CAf LFO2 TVA DEPTH	0 - 100.0 [%]	00	0 [%]
40 2x 30	00 00 01	28 - 58	PAf PITCH CONTROL	-24 - +24 [semitones]	40	0 [semitones]
40 2x 31	00 00 01	00 - 7F	PAf TVF CUTOFF CONTROL	-9600 - +9600 [cents]	40	0 [cents]
40 2x 32	00 00 01	00 - 7F	PAf AMPLITUDE CONTROL	-100.0 - +100.0 [%]	40	0 [%]
40 2x 33	00 00 01	00 - 7F	PAf LFO1 RATE CONTROL	-10.0 - +10.0 [Hz]	40	0 [Hz]
40 2x 34	00 00 01	00 - 7F	PAf LFO1 PITCH DEPTH	0 - 600 [cents]	00	0 [cents]
40 2x 35	00 00 01	00 - 7F	PAf LFO1 TVF DEPTH	0 - 2400 [cents]	00	0 [cents]
40 2x 36	00 00 01	00 - 7F	PAf LFO1 TVA DEPTH	0 - 100.0 [%]	00	0 [%]
40 2x 37	00 00 01	00 - 7F	PAf LFO2 RATE CONTROL	-10.0 - +10.0 [Hz]	40	0 [Hz]
40 2x 38	00 00 01	00 - 7F	PAf LFO2 PITCH DEPTH	0 - 600 [cents]	00	0 [cents]
40 2x 39	00 00 01	00 - 7F	PAf LFO2 TVF DEPTH	0 - 2400 [cents]	00	0 [cents]
40 2x 3A	00 00 01	00 - 7F	PAf LFO2 TVA DEPTH	0 - 100.0 [%]	00	0 [%]
40 2x 40	00 00 01	28 - 58	CC1 PITCH CONTROL	-24 - +24 [semitones]	40	0 [semitones]
40 2x 41	00 00 01	00 - 7F	CC1 TVF CUTOFF CONTROL	-9600 - +9600 [cents]	40	0 [cents]
40 2x 42	00 00 01	00 - 7F	CC1 AMPLITUDE CONTROL	-100.0 - +100.0 [%]	40	0 [%]
40 2x 43	00 00 01	00 - 7F	CC1 LFO1 RATE CONTROL	-10.0 - +10.0 [Hz]	40	0 [Hz]
40 2x 44	00 00 01	00 - 7F	CC1 LFO1 PITCH DEPTH	0 - 600 [cents]	00	0 [cents]
40 2x 45	00 00 01	00 - 7F	CC1 LFO1 TVF DEPTH	0 - 2400 [cents]	00	0 [cents]
40 2x 46	00 00 01	00 - 7F	CC1 LFO1 TVA DEPTH	0 - 100.0 [%]	00	0 [%]
40 2x 47	00 00 01	00 - 7F	CC1 LFO2 RATE CONTROL	-10.0 - +10.0 [Hz]	40	0 [Hz]
40 2x 48	00 00 01	00 - 7F	CC1 LFO2 PITCH DEPTH	0 - 600 [cents]	00	0 [cents]
40 2x 49	00 00 01	00 - 7F	CC1 LFO2 TVF DEPTH	0 - 2400 [cents]	00	0 [cents]
40 2x 4A	00 00 01	00 - 7F	CC1 LFO2 TVA DEPTH	0 - 100.0 [%]	00	0 [%]
40 2x 50	00 00 01	28 - 58	CC2 PITCH CONTROL	-24 - +24 [semitones]	40	0 [semitones]
40 2x 51	00 00 01	00 - 7F	CC2 TVF CUTOFF CONTROL	-9600 - +9600 [cents]	40	0 [cents]
40 2x 52	00 00 01	00 - 7F	CC2 AMPLITUDE CONTROL	-100.0 - +100.0 [%]	40	0 [%]
40 2x 53	00 00 01	00 - 7F	CC2 LFO1 RATE CONTROL	-10.0 - +10.0 [Hz]	40	0 [Hz]
40 2x 54	00 00 01	00 - 7F	CC2 LFO1 PITCH DEPTH	0 - 600 [cents]	00	0 [cents]
40 2x 55	00 00 01	00 - 7F	CC2 LFO1 TVF DEPTH	0 - 2400 [cents]	00	0 [cents]
40 2x 56	00 00 01	00 - 7F	CC2 LFO1 TVA DEPTH	0 - 100.0 [%]	00	0 [%]
40 2x 57	00 00 01	00 - 7F	CC2 LFO2 RATE CONTROL	-10.0 - +10.0 [Hz]	40	0 [Hz]
40 2x 58	00 00 01	00 - 7F	CC2 LFO2 PITCH DEPTH	0 - 600 [cents]	00	0 [cents]
40 2x 59	00 00 01	00 - 7F	CC2 LFO2 TVF DEPTH	0 - 2400 [cents]	00	0 [cents]
40 2x 5A	00 00 01	00 - 7F	CC2 LFO2 TVA DEPTH	0 - 100.0 [%]	00	0 [%]

\* You may not always be able to obtain the desired effect by modifying the LFO 1 and LFO 2 parameters.

Address (H)	Size (H)	Data (H)	Parameter	Description	Default Value (H)	Description
40 4x 22	00 00 01	00, 01	PART MFX ASSIGN	00: BYPASS 01: MFX	00	BYPASS

## ● Drum setup parameters (Model ID=42H)

m: Map number (0 = MAP1, 1 = MAP2)

rr: drum part note number (00H - 7FH: 0 - 127)

Address (H)	Size (H)	Data (H)	Parameter	Description
41 m1 rr	00 00 01	00 - 7F	PLAY NOTE NUMBER	Pitch coarse
41 m2 rr	00 00 01	00 - 7F	LEVEL	TVA level (=NRP# 26)
41 m3 rr	00 00 01	00 - 7F	ASSIGN GROUP NUMBER	Non, 1 - 127
41 m4 rr	00 00 01	00 - 7F	PANPOT	-64(RANDOM), -63(LEFT)- +63(RIGHT) (=NRP# 28, except RANDOM)
41 m5 rr	00 00 01	00 - 7F	REVERB SEND LEVEL	0.0 - 1.0 Multiplicand of the part reverb level (=NRP# 29)
41 m6 rr	00 00 01	00 - 7F	CHORUS SEND LEVEL	0.0 - 1.0 Multiplicand of the part chorus level (=NRP# 30)
41 m7 rr	00 00 01	00, 01	Rx. NOTE OFF	OFF/ON
41 m8 rr	00 00 01	00, 01	Rx. NOTE ON	OFF/ON

\* When the Drum Set is changed, DRUM SETUP PARAMETER values will all be initialized.



## 4. Bulk Dump

Bulk Dump allows you to transmit all User Programs/Song data at once, and is convenient for storing settings on a computer or sequencer. To make the E-09 perform a Bulk Dump transmission, send it a "Bulk Dump Request" message.

### ■ System Exclusive Message (Model ID=00 00 17H)

When an appropriate "Data Request 1 (RQ1)" message is received, the requested internal data will be transmitted as "Data Set 1 (DT1)".

#### ● Data Request 1 (RQ1)

<u>Status</u>	<u>Data byte</u>	<u>Status</u>
F0H	41H, dev, 00H, 00H, 17H, 11H, aaH, bbH, ccH, ddH, ssH, ttH, uuH, vvH, sum	F7H

<u>Byte</u>	<u>Explanation</u>
F0H	Exclusive status
41H	ID number (Roland)
dev	Device ID (dev: 00H - 1FH, Initial value is 10H)
00H 00H 17H	Model ID (E-09)
11H	Command ID (RQ1)
aaH	Address MSB
bbH	Address
ccH	Address
ddH	Address LSB
ssH	Size MSB
ttH	Size
uuH	Size
vvH	Size LSB
sum	Checksum
F7H	EOX (End Of Exclusive)

\* Regarding the checksum, refer to "5. Supplementary material", Example of an Exclusive message and calculating a checksum (p. 19).

# Roland E-09 MIDI Implementation

## ●Data Set 1 (DT1)

Status	Data byte	Status
F0H	41H, dev, 00H, 00H, 17H, 12H, aaH, bbH, ccH, ddH, eeH, ..., sum	F7H

Byte	Explanation
F0H	Exclusive status
41H	ID number (Roland)
dev	Device ID (dev: 00H - 1FH, Initial value is 10H)
00H 00H 17H	Model ID (E-09)
12H	Command ID (DT1)
aaH	Address MSB
bbH	Address:
ccH	Address:
ddH	Address LSB
eeH	Data
:	:
sum	Checksum
F7H	EOX (End Of Exclusive)

## ●User program dump request (receive only)

This is a command that requests a set of user program data, and uses "Data Request 1 (RQ1)" format.

Address: 10H bbH 00H 00H    bb: user program number (00H - 63H: 00 - 99)  
 Size: 00H ttH 00H 00H    tt: request size (01H - 64H: 1 - 100)

Example) Dump request for all user programs: F0 41 10 00 00 17 11 10 00 00 00 00 64 00 00 0C F7

## ●User song dump request (receive only)

This is a command that requests a set of user song data, and uses "Data Request 1 (RQ1)" format.

Address: 40H 00H 00H 00H  
 Size: 00H 01H 00H 00H

Example) Dump request for user song: F0 41 10 00 00 17 11 40 00 00 00 01 00 00 3F F7

## 5. Supplementary material

### ■Decimal and Hexadecimal table

(An "H" is appended to the end of numbers in hexadecimal notation.)

In MIDI documentation, data values and addresses/sizes of Exclusive messages, etc. are expressed as hexadecimal values for each 7 bits.

The following table shows how these correspond to decimal numbers.

Dec.	Hex.	Dec.	Hex.	Dec.	Hex.	Dec.	Hex.
0	00H	32	20H	64	40H	96	60H
1	01H	33	21H	65	41H	97	61H
2	02H	34	22H	66	42H	98	62H
3	03H	35	23H	67	43H	99	63H
4	04H	36	24H	68	44H	100	64H
5	05H	37	25H	69	45H	101	65H
6	06H	38	26H	70	46H	102	66H
7	07H	39	27H	71	47H	103	67H
8	08H	40	28H	72	48H	104	68H
9	09H	41	29H	73	49H	105	69H
10	0AH	42	2AH	74	4AH	106	6AH
11	0BH	43	2BH	75	4BH	107	6BH
12	0CH	44	2CH	76	4CH	108	6CH
13	0DH	45	2DH	77	4DH	109	6DH
14	0EH	46	2EH	78	4EH	110	6EH
15	0FH	47	2FH	79	4FH	111	6FH
16	10H	48	30H	80	50H	112	70H
17	11H	49	31H	81	51H	113	71H
18	12H	50	32H	82	52H	114	72H
19	13H	51	33H	83	53H	115	73H
20	14H	52	34H	84	54H	116	74H
21	15H	53	35H	85	55H	117	75H
22	16H	54	36H	86	56H	118	76H
23	17H	55	37H	87	57H	119	77H
24	18H	56	38H	88	58H	120	78H
25	19H	57	39H	89	59H	121	79H
26	1AH	58	3AH	90	5AH	122	7AH
27	1BH	59	3BH	91	5BH	123	7BH
28	1CH	60	3CH	92	5CH	124	7CH
29	1DH	61	3DH	93	5DH	125	7DH
30	1EH	62	3EH	94	5EH	126	7EH
31	1FH	63	3FH	95	5FH	127	7FH

\* Decimal values such as MIDI channel, bank select, and program change are listed as one greater than the values given in the above table.  
 \* A 7-bit byte can express data in the range of 128 steps. For data where greater precision

is required, we must use two or more bytes. For example, two hexadecimal numbers aa bbH expressing two 7-bit bytes would indicate a value of aa x 128+bb.

\* In the case of values which have a +/- sign, 00H = -64, 40H = +/-0, and 7FH = +63, so that the decimal expression would be 64 less than the value given in the above chart. In the case of two types, 00 00H = -8192, 40 00H = +/-0, and 7F 7FH = +8191. For example, if aa bbH were expressed as decimal, this would be aa bbH - 40 00H = aa x 128+bb - 64 x 128.

\* Data marked "Use nibbled data" is expressed in hexadecimal in 4-bit units. A value expressed as a 2-byte nibble 0a 0bH has the value of a x 16+b.

### [Example 1] What is the decimal expression of 5AH ?

From the preceding table, 5AH = 90

### [Example 2] What is the decimal expression of the value 12 34H given as hexadecimal for each 7 bits?

From the preceding table, since 12H = 18 and 34H = 52  
 18 x 128+52 = 2356

### [Example 3] What is the decimal expression of the nibbled value 0A 03 0D ?

From the preceding table, since 0AH = 10, 03H = 3, 09H = 9, 0DH = 13  
 ((10 x 16+3) x 16+9) x 16+13 = 41885

### [Example 4] What is the nibbled expression of the decimal value 1258?

16) 1258  
 16) 78 ... 10  
 16) 4 ... 14  
 0 ... 4

Since from the preceding table, 0 = 00H, 4 = 04H, 14 = 0EH, 10 = 0AH, the result is: 00 04 0E 0AH.

## ■Examples of actual MIDI messages

### [Example 1] 92 3E 5F

9n is the Note-on status, and n is the MIDI channel number. Since 2H = 2, 3EH = 62, and 5FH = 95, this is a Note-on message with MIDI CH = 3, note number 62 (note name is D4), and velocity 95.

### [Example 2] CE 49

CnH is the Program Change status, and n is the MIDI channel number. Since EH = 14 and 49H = 73, this is a Program Change message with MIDI CH = 15, program number 74 (Flute in GS).

### [Example 3] EA 00 28

EnH is the Pitch Bend Change status, and n is the MIDI channel number. The 2nd byte (00H = 0) is the LSB and the 3rd byte (28H = 40) is the MSB, but Pitch Bend Value is a signed number in which 40 00H (= 64 x 12+80 = 8192) is 0, so this Pitch Bend Value is 28 00H - 40 00H = 40 x 12+80 - (64 x 12+80) = 5120 - 8192 = -3072.

If the Pitch Bend Sensitivity is set to 2 semitones, -8192 (00 00H) will cause the pitch to change by -200 cents, so in this case -200 x (-3072) ÷ (-8192) = -75 cents of Pitch Bend is being applied to MIDI channel 11.

### [Example 4] B3 64 00 65 00 06 0C 26 00 64 7F 65 7F

BnH is the Control Change status, and n is the MIDI channel number. For Control Changes, the 2nd byte is the control number, and the 3rd byte is the value. In a case in which two or more consecutive messages have the same status, MIDI has a provision called "running status" which allows the status byte of the second and following messages to be omitted. Thus, the above messages have the following meaning.

- B3    64 00    MIDI ch.4, lower byte of RPN parameter number:    00H
- (B3) 65 00    (MIDI ch.4) upper byte of RPN parameter number:    00H
- (B3) 06 0C    (MIDI ch.4) upper byte of parameter value:    0CH
- (B3) 26 00    (MIDI ch.4) lower byte of parameter value:    00H
- (B3) 64 7F    (MIDI ch.4) lower byte of RPN parameter number:    7FH
- (B3) 65 7F    (MIDI ch.4) upper byte of RPN parameter number:    7FH

In other words, the above messages specify a value of 0C 00H for RPN parameter number 00 00H on MIDI channel 4, and then set the RPN parameter number to 7F 7FH.

RPN parameter number 00 00H is Pitch Bend Sensitivity, and the MSB of the value indicates semitone units, so a value of 0CH = 12 sets the maximum pitch bend range to +/-12 semitones (1 octave). (On GS sound generators the LSB of Pitch Bend Sensitivity is ignored,

but the LSB should be transmitted anyway (with a value of 0) so that operation will be correct on any device.)

Once the parameter number has been specified for RPN or NRPN, all Data Entry messages transmitted on that same channel will be valid, so after the desired value has been transmitted, it is a good idea to set the parameter number to 7F 7FH to prevent accidents. This is the reason for the (B3) 64 7F (B3) 65 7F at the end.

It is not desirable for performance data (such as Standard MIDI File data) to contain many events with running status as given in [Example 4]. This is because if playback is halted during the song and then rewound or fast-forwarded, the sequencer may not be able to transmit the correct status, and the sound generator will then misinterpret the data. Take care to give each event its own status.

It is also necessary that the RPN or NRPN parameter number setting and the value setting be done in the proper order. On some sequencers, events occurring in the same (or consecutive) clock may be transmitted in an order different than the order in which they were received. For this reason it is a good idea to slightly skew the time of each event (about 1 tick for TPQN = 96, and about 5 ticks for TPQN = 480).

\* TPQN: Ticks Per Quarter Note

## ■ Example of an Exclusive message and calculating a checksum

Roland Exclusive messages (RQ1, DT1) are transmitted with a checksum at the end (before F7) to make sure that the message was correctly received. The value of the checksum is determined by the address and data (or size) of the transmitted Exclusive message.

### ○ How to calculate the checksum (hexadecimal numbers are indicated by "H")

The checksum is a value derived by adding the address, size, and checksum itself and inverting the lower 7 bits.

Here's an example of how the checksum is calculated. We will assume that in the Exclusive message we are transmitting, the address is aa bb ccH and the data or size is dd ee ffH.

$$\begin{aligned} aa+bb+cc+dd+ee+ff &= \text{sum} \\ \text{sum} \div 128 &= \text{quotient} \dots \text{remainder} \\ 128 - \text{remainder} &= \text{checksum} \end{aligned}$$

#### [Example 1] Setting REVERB MACRO to ROOM 3

According to the "Parameter Address Map," the REVERB MACRO Address is 40 01 30H, and ROOM 3 is a value of 02H. Thus:

```
F0 41 10 42 12 40 01 30 02 ?? F7
(1) (2) (3) (4) (5) address data checksum (6)
```

- (1) Exclusive Status,           (2) ID (Roland),               (3) Device ID (17),
- (4) Model ID (GS),           (5) Command ID (DT1),       (6) End of Exclusive

Next, we calculate the checksum.

$$\begin{aligned} 40H + 01H + 30H + 02H &= 64 + 1 + 48 + 2 = 115 (\text{sum}) \\ 115 (\text{sum}) \div 128 &= 0 (\text{quotient}) \dots 115 (\text{remainder}) \\ \text{checksum} &= 128 - 115 (\text{remainder}) = 13 = 0DH \end{aligned}$$

This means that F0 41 10 42 12 40 01 30 02 0D F7 is the message we transmit.

#### [Example 2] Setting REVERB LEVEL to 12

According to the "Parameter Address Map," the REVERB LEVEL Address is 40 01 33H, and the parameter value is 0CH. Thus:

```
F0 41 10 42 12 40 01 33 0C ?? F7
(1) (2) (3) (4) (5) address data checksum (6)
```

- (1) Exclusive Status,           (2) ID (Roland),               (3) Device ID (17),
- (4) Model ID (GS),           (5) Command ID (DT1),       (6) End of Exclusive

Next, we calculate the checksum.

$$\begin{aligned} 40H + 01H + 33H + 0CH &= 64 + 1 + 51 + 12 = 128 (\text{sum}) \\ 128 (\text{sum}) \div 128 &= 0 (\text{quotient}) \dots 0 (\text{remainder}) \\ \text{checksum} &= 128 - 0 (\text{remainder}) = 128 = 80H \end{aligned}$$

In this case, however, the checksum value should be 00H, not 80H. You should use 00H if the remainder is 0.

This means that F0 41 10 42 12 40 01 33 0C 00 F7 is the message we transmit.

## ■ About the Tuning

In MIDI, individual Parts are tuned by sending RPN #1 (Channel Fine Tuning) to the appropriate MIDI channel.

In MIDI, an entire device is tuned by either sending RPN #1 to all MIDI channels being used, or by sending a System Exclusive MASTER TUNE (address 40 00 00H).

RPN #1 allows tuning to be specified in steps of approximately 0.012 cents (to be precise, 100/8192 cent), and System Exclusive MASTER TUNE allows tuning in steps of 0.1 cent. One cent is 1/100th of a semitone.

The values of RPN #1 (Channel Fine Tuning) and System Exclusive MASTER TUNE are added together to determine the actual pitch sounded by each Part.

Frequently used tuning values are given in the following table for your reference. Values are in hexadecimal (decimal in parentheses).

Hz at A4	Cents	RPN #1	Sys.Ex. 40 00 00
445.0	+19.56	4C 43 (+1603)	00 04 0C 04 (+196)
444.0	+15.67	4A 03 (+1283)	00 04 09 0D (+157)
443.0	+11.76	47 44 (+964)	00 04 07 06 (+118)
442.0	+ 7.85	45 03 (+643)	00 04 04 0F (+79)
441.0	+ 3.93	42 42 (+322)	00 04 02 07 (+39)
440.0	0	40 00 (0)	00 04 00 00 (0)
439.0	- 3.94	3D 3D (-323)	00 03 0D 09 (-39)
438.0	- 7.89	3A 7A (-646)	00 03 0B 01 (-79)

### [Example] Setting the tuning of MIDI channel 3 to A4 = 442.0 Hz

Send RPN#1 to MIDI channel 3. From the above table, the value is 45 03H.

- B2 64 01 MIDI ch.3, lower byte of RPN parameter number: 01H
- (B2) 65 00 (MIDI ch.3) upper byte of RPN parameter number: 00H
- (B2) 06 45 (MIDI ch.3) upper byte of parameter value: 45H
- (B2) 26 03 (MIDI ch.3) lower byte of parameter value: 03H
- (B2) 64 7F (MIDI ch.3) lower byte of RPN parameter number: 7FH
- (B2) 65 7F (MIDI ch.3) upper byte of RPN parameter number: 7FH

## ● The Scale Tune Feature (address: 40 1x 40)

The scale Tune feature allows you to finely adjust the individual pitch of the notes from C through B. Though the settings are made while working with one octave, the fine adjustments will affect all octaves. By making the appropriate Scale Tune settings, you can obtain a complete variety of tuning methods other than equal temperament. As examples, three possible types of scale setting are explained below.

### ○ Equal Temperament

This method of tuning divides the octave into 12 equal parts. It is currently the most widely used form of tuning, especially in occidental music. On the E-09, the default settings for the Scale Tune feature produce equal temperament.

### ○ Just Temperament (Tonic of C)

The principal triads resound much more beautifully than with equal temperament, but this benefit can only be obtained in one key. If transposed, the chords tend to become ambiguous. The example given involves settings for a key in which C is the keynote.

### ○ Arabic Scale

By altering the setting for Scale Tune, you can obtain a variety of other tunings suited for ethnic music. For example, the settings introduced below will set the unit to use the Arabic Scale.

Example Settings

Note Name	Equal Temperament	Just Temperament (Keytone C)	Arabic Scale
C	0	0	-6
C#	0	-8	+45
D	0	+4	-2
D#	0	+16	-12
E	0	-14	-51
F	0	-2	-8
F#	0	-10	+43
G	0	+2	-4
G#	0	+14	+47
Note Name	Equal Temperament	Just Temperament (Keytone C)	Arabic Scale
A	0	-16	0
A#	0	+14	-10
B	0	-12	-49

The values in the table are given in cents. Refer to the explanation of Scale Tuning on page 15 to convert these values to hexadecimal, and transmit them as Exclusive data.

For example, to set the tune (C-B) of the Part1 Arabic Scale, send the following data:

```
F0 41 10 42 12 40 11 40 3A 6D 3E 34 0D 38 6B 3C 6F 40 36 0F 76 F7
```